



## PRODUCT-DETAILS

**1724-4073****Cover frame 4-gang aluminium silver - Busch-art linear****General Information**

|                               |  |
|-------------------------------|--|
| <b>Extended Product Type:</b> | 1724-4073  |
| <b>Product ID:</b>            | 2CLA897400A1758  |
| <b>EAN:</b>                   | 8427238272412  |
| <b>Catalog Description:</b>   | Cover frame 4-gang aluminium silver - Busch-art linear |
| <b>Long Description:</b>      | For vertical or horizontal installation.               |
| <b>Display Name:</b>          | 1724-4073  |

**Installation**

|                                     |                        |
|-------------------------------------|------------------------|
| <b>Instructions and Manuals:</b>    | No document needed     |
| <b>Mounting Type:</b>               | Flush Mounted          |
| <b>Type of Fastening:</b>           | Clamp                  |
| <b>Mounting Orientation:</b>        | Horizontal<br>Vertical |
| <b>Modular Components Included:</b> | Cover Frame            |

---

## Environmental

---

**Degree of Protection:** IP20

---



---

## Technical

---

**Data Sheet, Technical Information:** No document needed

---

**Options Available:** "basic"

---



---

## Design

---

**Design Range:** Busch-art linear

---

**Design Range Variant:** Busch-art linear - pur

---

**Surface Finishing:** Matt  
Untreated

---

**Material:** Aluminium  
Metal

---

**Material Details:** Genuine Metal Surface

---

**Label Space Provided:** Without Label Space

---

**Color:** aluminium silver

---

**Number of Gangs:** 4-gang

---

**Number of Modules:** Horizontal 4  
Vertical 4

---



---

## Dimensions

---

**Product Net Width:** 85 mm

---

**Product Net Height:** 8.6 mm

---

**Product Net Depth / Length:** 298.3 mm

---

**Product Net Weight:** 128 g

---

**Dimension Diagram:** 9AKK108471A3893

---



---

## Engineering

---

**Building Information Modeling – BIM:** 9AKK108471A9963  
9AKK108471A9951

---



---

## Material Compliance

---

**RoHS Declaration:** 2CLC00000009438

---

**RoHS Information:** Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019

---

**REACH Declaration:** 2CLC00000009438

---

|   |   |
|---|---|
| <b>REACH Information:</b>                           | False - does not contain substances > 0.1 mass percentage |
| <b>REACH Date:</b>                                  | 20251231  |
| <b>Conflict Minerals Reporting Template (CMRT):</b> | 9AKK108468A3363   |
| <b>WEEE Category:</b>                               | Product Not in WEEE Scope                                 |

## Certificates and Declarations

|  |                       |
|--|-----------------------|
| <b>Declaration of Conformity - CE:</b>           | No declaration needed |
| <b>EU Data Act Applicability and Compliance:</b> | Not Applicable        |

## External Classifications and Standards

|                 |   |
|-----------------|---|
| <b>ETIM 9:</b>  | EC000007 - Cover frame for domestic switching devices |
| <b>ETIM 10:</b> | EC000007 - Cover frame for domestic switching devices |
| <b>eClass:</b>  | V11.0 : 27144001                                      |

## Accessories

| Identifier      | Description   | Type         | Qty | Unit Of Measure |
|-----------------|---|--------------|-----|-----------------|
| 2CKA001751A3333 | Rocker for Switch/push button, Single rocker studio white - Busch-art linear      | 1786-44G     | 1   | piece           |
| 2CKA001751A3334 | Rocker for Switch/push button, Single rocker studio white matt - Busch-art linear | 1786-44M     | 1   | piece           |
| 2CKA001751A3336 | Rocker for Switch/push button, Single rocker black matt - Busch-art linear        | 1786-45M     | 1   | piece           |
| 2CKA001751A3337 | Rocker for Switch/push button, Single rocker studio white - Busch-art linear      | 1786-44G-500 | 1   | piece           |
| 2CKA001751A3338 | Rocker for Switch/push button, Single rocker studio white matt - Busch-art linear | 1786-44M-500 | 1   | piece           |
| 2CKA001751A3340 | Rocker for Switch/push button, Single rocker black matt - Busch-art linear        | 1786-45M-500 | 1   | piece           |
| 2CKA002013A5489 | SCHUKO® socket insert Safety Shutter studio white - Busch-art linear              | 20 EUCB-44G  | 1   | piece           |
| 2CKA002013A5490 | SCHUKO® socket insert Safety Shutter studio white matt - Busch-art linear         | 20 EUCB-44M  | 1   | piece           |

|                 |  |                 |   |       |
|-----------------|--|-----------------|---|-------|
| 2CKA002013A5492 | SCHUKO® socket insert<br>Safety Shutter black matt<br>- Busch-art linear   | 20 EUCB-45M     | 1 | piece |
| 2CKA002013A5493 | Socket insert Safety<br>Shutter studio white -<br>Busch-art linear   | 20 EUCB-44G-500 | 1 | piece |
| 2CKA002013A5494 | Socket insert Safety<br>Shutter studio white matt<br>- Busch-art linear  | 20 EUCB-44M-500 | 1 | piece |
| 2CKA002013A5496 | Socket insert Safety<br>Shutter black matt -<br>Busch-art linear   | 20 EUCB-45M-500 | 1 | piece |
| 2CKA001751A3409 | Rocker with Small<br>Transparent Calotte for<br>Switch/push button,<br>Single rocker studio white<br>- Busch-art linear      | 1789 NWD-44G    | 1 | piece |
| 2CKA001751A3410 | Rocker with Small<br>Transparent Calotte for<br>Switch/push button,<br>Single rocker studio white<br>matt - Busch-art linear | 1789 NWD-44M    | 1 | piece |
| 2CKA001751A3412 | Rocker with Small<br>Transparent Calotte for<br>Switch/push button,<br>Single rocker black matt -<br>Busch-art linear        | 1789 NWD-45M    | 1 | piece |
| 2CKA001751A3341 | Rocker with legend<br>Symbol "bell" for<br>Switch/push button,<br>Single rocker studio white<br>- Busch-art linear           | 2520 KI-44G     | 1 | piece |
| 2CKA001751A3342 | Rocker with legend<br>Symbol "bell" for<br>Switch/push button,<br>Single rocker studio white<br>matt - Busch-art linear      | 2520 KI-44M     | 1 | piece |
| 2CKA001751A3344 | Rocker with legend<br>Symbol "bell" for<br>Switch/push button,<br>Single rocker black matt -<br>Busch-art linear             | 2520 KI-45M     | 1 | piece |
| 2CKA001751A3345 | Rocker with legend<br>Symbol "light" for<br>Switch/push button,<br>Single rocker studio white<br>- Busch-art linear          | 2520 LI-44G     | 1 | piece |
| 2CKA001751A3346 | Rocker with legend<br>Symbol "light" for<br>Switch/push button,<br>Single rocker studio white<br>matt - Busch-art linear     | 2520 LI-44M     | 1 | piece |
| 2CKA001751A3348 | Rocker with legend<br>Symbol "light" for<br>Switch/push button,<br>Single rocker black matt -<br>Busch-art linear            | 2520 LI-45M     | 1 | piece |
| 2CKA001751A3349 | Rocker with legend<br>Symbol "key" for<br>Switch/push button,<br>Single rocker studio white<br>- Busch-art linear            | 2520 TR-44G     | 1 | piece |

|                 |  |             |   |       |
|-----------------|--|-------------|---|-------|
| 2CKA001751A3350 | Rocker with legend<br>Symbol "key" for<br>Switch/push button,<br>Single rocker studio white<br>matt - Busch-art linear   | 2520 TR-44M | 1 | piece |
| 2CKA001751A3352 | Rocker with legend<br>Symbol "key" for<br>Switch/push button,<br>Single rocker black matt -<br>Busch-art linear  | 2520 TR-45M | 1 | piece |
| 2CKA001731A4021 | Rocker with labelling field 1764 N-44G<br>for Switch/push button,<br>Single rocker studio white<br>- Busch-art linear  |             | 1 | piece |
| 2CKA001731A4022 | Rocker with labelling field 1764 N-44M<br>for Switch/push button,<br>Single rocker studio white<br>matt - Busch-art linear                                     |             | 1 | piece |
| 2CKA001731A4024 | Rocker with labelling field 1764 N-45M<br>for Switch/push button,<br>Single rocker black matt -<br>Busch-art linear  |             | 1 | piece |
| 2CKA001731A4025 | Rocker with labelling field 1764 N/KI-44G<br>and legend Symbol "bell"<br>for Switch/push button,<br>Single rocker studio white<br>- Busch-art linear           |             | 1 | piece |
| 2CKA001731A4026 | Rocker with labelling field 1764 N/KI-44M<br>and legend Symbol "bell"<br>for Switch/push button,<br>Single rocker studio white<br>matt - Busch-art linear      |             | 1 | piece |
| 2CKA001731A4028 | Rocker with labelling field 1764 N/KI-45M<br>and legend Symbol "bell"<br>for Switch/push button,<br>Single rocker black matt -<br>Busch-art linear             |             | 1 | piece |
| 2CKA001751A3353 | Rocker with legend<br>Characters 0 and 1 with<br>Small Transparent Calotte<br>for Switch/push button,<br>Single rocker studio white<br>- Busch-art linear      | 1788-44G    | 1 | piece |
| 2CKA001751A3354 | Rocker with legend<br>Characters 0 and 1 with<br>Small Transparent Calotte<br>for Switch/push button,<br>Single rocker studio white<br>matt - Busch-art linear | 1788-44M    | 1 | piece |
| 2CKA001751A3356 | Rocker with legend<br>Characters 0 and 1 with<br>Small Transparent Calotte<br>for Switch/push button,<br>Single rocker black matt -<br>Busch-art linear        | 1788-45M    | 1 | piece |
| 2CKA001751A3357 | Rocker with legend<br>Heizung with Small Red<br>Calotte for Switch/push<br>button, Single rocker<br>studio white - Busch-art<br>linear                         | 1789 H-44G  | 1 | piece |

|                 |  |                |   |       |
|-----------------|--|----------------|---|-------|
| 2CKA001751A3358 | Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear               | 1789 H-44M     | 1 | piece |
| 2CKA001751A3360 | Rocker with legend Heizung with Small Red Calotte for Switch/push button, Single rocker black matt - Busch-art linear                      | 1789 H-45M     | 1 | piece |
| 2CKA001751A3361 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white - Busch-art linear                                | 1789 N-44G     | 1 | piece |
| 2CKA001751A3362 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear                           | 1789 N-44M     | 1 | piece |
| 2CKA001751A3364 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker black matt - Busch-art linear                                  | 1789 N-45M     | 1 | piece |
| 2CKA001751A3365 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white - Busch-art linear                                | 1789 N-44G-500 | 1 | piece |
| 2CKA001751A3366 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear                           | 1789 N-44M-500 | 1 | piece |
| 2CKA001751A3368 | Rocker with Small Transparent Calotte for Switch/push button, Single rocker black matt - Busch-art linear                                  | 1789 N-45M-500 | 1 | piece |
| 2CKA001751A3369 | Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Busch-art linear      | 1789 KI-44G    | 1 | piece |
| 2CKA001751A3370 | Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Busch-art linear | 1789 KI-44M    | 1 | piece |
| 2CKA001751A3372 | Rocker with legend Symbol "bell" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Busch-art linear        | 1789 KI-45M    | 1 | piece |

|                 |   |             |   |       |
|-----------------|---|-------------|---|-------|
| 2CKA001751A3373 | Rocker with legend<br>Symbol "light" with Small<br>Transparent Calotte for<br>Switch/push button,<br>Single rocker studio white<br>- Busch-art linear       | 1789 LI-44G | 1 | piece |
| 2CKA001751A3374 | Rocker with legend<br>Symbol "light" with Small<br>Transparent Calotte for<br>Switch/push button,<br>Single rocker studio white<br>matt - Busch-art linear  | 1789 LI-44M | 1 | piece |
| 2CKA001751A3376 | Rocker with legend<br>Symbol "light" with Small<br>Transparent Calotte for<br>Switch/push button,<br>Single rocker black matt -<br>Busch-art linear         | 1789 LI-45M | 1 | piece |
| 2CKA001751A3377 | Rocker with legend<br>Symbol "key" with Small<br>Transparent Calotte for<br>Switch/push button,<br>Single rocker studio white<br>- Busch-art linear         | 1789 TR-44G | 1 | piece |
| 2CKA001751A3378 | Rocker with legend<br>Symbol "key" with Small<br>Transparent Calotte for<br>Switch/push button,<br>Single rocker studio white<br>matt - Busch-art linear    | 1789 TR-44M | 1 | piece |
| 2CKA001751A3380 | Rocker with legend<br>Symbol "key" with Small<br>Transparent Calotte for<br>Switch/push button,<br>Single rocker black matt -<br>Busch-art linear           | 1789 TR-45M | 1 | piece |
| 2CKA001751A3381 | Rocker with legend<br>Symbol "Socket" with<br>Small Transparent Calotte<br>for Switch/push button,<br>Single rocker studio white<br>- Busch-art linear      | 1789 ST-44G | 1 | piece |
| 2CKA001751A3382 | Rocker with legend<br>Symbol "Socket" with<br>Small Transparent Calotte<br>for Switch/push button,<br>Single rocker studio white<br>matt - Busch-art linear | 1789 ST-44M | 1 | piece |
| 2CKA001751A3384 | Rocker with legend<br>Symbol "Socket" with<br>Small Transparent Calotte<br>for Switch/push button,<br>Single rocker black matt -<br>Busch-art linear        | 1789 ST-45M | 1 | piece |
| 2CKA001751A3305 | Rocker with Small<br>Transparent Calotte for<br>Switch/push button, Two<br>-part rocker studio white -<br>Busch-art linear                                  | 1785 K-44G  | 1 | piece |
| 2CKA001751A3306 | Rocker with Small<br>Transparent Calotte for<br>Switch/push button, Two<br>-part rocker studio white<br>matt - Busch-art linear                             | 1785 K-44M  | 1 | piece |

|                 |   |                 |   |       |
|-----------------|---|-----------------|---|-------|
| 2CKA001751A3308 | Rocker with Small Transparent Calotte for Switch/push button, Two-part rocker black matt - Busch-art linear | 1785 K-45M      | 1 | piece |
| 2CKA001751A3385 | Rocker for Switch/push button, Two-part rocker studio white - Busch-art linear                              | 1785-44G        | 1 | piece |
| 2CKA001751A3386 | Rocker for Switch/push button, Two-part rocker studio white matt - Busch-art linear                         | 1785-44M        | 1 | piece |
| 2CKA001751A3388 | Rocker for Switch/push button, Two-part rocker black matt - Busch-art linear                                | 1785-45M        | 1 | piece |
| 2CKA001751A3389 | Rocker for Switch/push button, Two-part rocker studio white - Busch-art linear                              | 1785-44G-500    | 1 | piece |
| 2CKA001751A3390 | Rocker for Switch/push button, Two-part rocker studio white matt - Busch-art linear                         | 1785-44M-500    | 1 | piece |
| 2CKA001751A3392 | Rocker for Switch/push button, Two-part rocker black matt - Busch-art linear                                | 1785-45M-500    | 1 | piece |
| 2CKA001751A3393 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white - Busch-art linear      | 1785 JA-44G     | 1 | piece |
| 2CKA001751A3394 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white matt - Busch-art linear | 1785 JA-44M     | 1 | piece |
| 2CKA001751A3396 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker black matt - Busch-art linear        | 1785 JA-45M     | 1 | piece |
| 2CKA001751A3397 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white - Busch-art linear      | 1785 JA-44G-500 | 1 | piece |
| 2CKA001751A3398 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white matt - Busch-art linear | 1785 JA-44M-500 | 1 | piece |
| 2CKA001751A3400 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker black matt - Busch-art linear        | 1785 JA-45M-500 | 1 | piece |

|                 |  |                    |   |       |
|-----------------|--|--------------------|---|-------|
| 2CKA002011A6316 | SCHUKO® USB socket insert Safety Shutter with USB A/C studio white - Busch-art linear      | 20 EUCB2USBAC-44G  | 1 | piece |
| 2CKA002011A6318 | SCHUKO® USB socket insert Safety Shutter with USB A/C studio white matt - Busch-art linear | 20 EUCB2USBAC-44M  | 1 | piece |
| 2CKA002011A6322 | SCHUKO® USB socket insert Safety Shutter with USB A/C black matt - Busch-art linear        | 20 EUCB2USBAC-45M  | 1 | piece |
| 2CKA002013A5521 | SCHUKO® socket insert flat Safety Shutter studio white - Busch-art linear                  | 20-1 EUCBF-44G     | 1 | piece |
| 2CKA002013A5522 | SCHUKO® socket insert flat Safety Shutter studio white matt - Busch-art linear             | 20-1 EUCBF-44M     | 1 | piece |
| 2CKA002013A5524 | SCHUKO® socket insert flat Safety Shutter black matt - Busch-art linear                    | 20-1 EUCBF-45M     | 1 | piece |
| 2CKA002013A5525 | Socket insert Safety Shutter studio white - Busch-art linear                               | 20-1 EUCBF-44G-500 | 1 | piece |
| 2CKA002013A5526 | Socket insert Safety Shutter studio white matt - Busch-art linear                          | 20-1 EUCBF-44M-500 | 1 | piece |
| 2CKA002013A5528 | Socket insert Safety Shutter black matt - Busch-art linear                                 | 20-1 EUCBF-45M-500 | 1 | piece |
| 2CKA002017A1905 | Socket insert flat with earthing pin Safety Shutter studio white - Busch-art linear        | 20-1 MUCB-44G      | 1 | piece |
| 2CKA002017A1906 | Socket insert flat with earthing pin Safety Shutter studio white matt - Busch-art linear   | 20-1 MUCB-44M      | 1 | piece |
| 2CKA002017A1908 | Socket insert flat with earthing pin Safety Shutter black matt - Busch-art linear          | 20-1 MUCB-45M      | 1 | piece |
| 2CKA002013A5497 | SCHUKO® socket insert Safety Shutter without claw studio white - Busch-art linear          | 20 EUCRB-44G       | 1 | piece |
| 2CKA002013A5498 | SCHUKO® socket insert Safety Shutter without claw studio white matt - Busch-art linear     | 20 EUCRB-44M       | 1 | piece |
| 2CKA002013A5500 | SCHUKO® socket insert Safety Shutter without claw black matt - Busch-art linear            | 20 EUCRB-45M       | 1 | piece |
| 2CKA002013A5501 | Socket insert Safety Shutter without claw studio white - Busch-art linear                  | 20 EUCRB-44G-500   | 1 | piece |

|                 |   |                  |   |       |
|-----------------|---|------------------|---|-------|
| 2CKA002013A5502 | Socket insert Safety Shutter without claw studio white matt - Busch-art linear                          | 20 EUCRB-44M-500 | 1 | piece |
| 2CKA002013A5504 | Socket insert Safety Shutter without claw black matt - Busch-art linear                                 | 20 EUCRB-45M-500 | 1 | piece |
| 2CKA002013A5505 | SCHUKO® socket insert Safety Shutter with screw terminals studio white - Busch-art linear               | 23 EUCB-44G      | 1 | piece |
| 2CKA002013A5506 | SCHUKO® socket insert Safety Shutter with screw terminals studio white matt - Busch-art linear          | 23 EUCB-44M      | 1 | piece |
| 2CKA002013A5508 | SCHUKO® socket insert Safety Shutter with screw terminals black matt - Busch-art linear                 | 23 EUCB-45M      | 1 | piece |
| 2CKA002013A5509 | SCHUKO® socket insert Safety Shutter with label space studio white - Busch-art linear                   | 20 EUCNB-44G     | 1 | piece |
| 2CKA002013A5510 | SCHUKO® socket insert Safety Shutter with label space studio white matt - Busch-art linear              | 20 EUCNB-44M     | 1 | piece |
| 2CKA002013A5512 | SCHUKO® socket insert Safety Shutter with label space black matt - Busch-art linear                     | 20 EUCNB-45M     | 1 | piece |
| 2CKA002013A5513 | SCHUKO® socket insert Safety Shutter with LED Control light /Green studio white - Busch-art linear      | 20 EUCBL-44G     | 1 | piece |
| 2CKA002013A5514 | SCHUKO® socket insert Safety Shutter with LED Control light /Green studio white matt - Busch-art linear | 20 EUCBL-44M     | 1 | piece |
| 2CKA002013A5516 | SCHUKO® socket insert Safety Shutter with LED Control light /Green black matt - Busch-art linear        | 20 EUCBL-45M     | 1 | piece |
| 2CKA002018A1579 | SCHUKO® socket insert Safety Shutter with Hinged Lid without claw studio white - Busch-art linear       | 20 EUKBR-44G     | 1 | piece |
| 2CKA002018A1580 | SCHUKO® socket insert Safety Shutter with Hinged Lid without claw studio white matt - Busch-art linear  | 20 EUKBR-44M     | 1 | piece |
| 2CKA002018A1582 | SCHUKO® socket insert Safety Shutter with Hinged Lid without claw black matt - Busch-art linear         | 20 EUKBR-45M     | 1 | piece |

|                 |   |                |   |       |
|-----------------|---|----------------|---|-------|
| 2CKA002013A5517 | Busch-steplight®<br>SCHUKO® socket insert<br>Safety Shutter with LED<br>Night light /White studio<br>white - Busch-art linear         | 20 EUCBLI-44G  | 1 | piece |
| 2CKA002013A5518 | Busch-steplight®<br>SCHUKO® socket insert<br>Safety Shutter with LED<br>Night light /White studio<br>white matt - Busch-art<br>linear | 20 EUCBLI-44M  | 1 | piece |
| 2CKA002013A5520 | Busch-steplight®<br>SCHUKO® socket insert<br>Safety Shutter with LED<br>Night light /White black<br>matt - Busch-art linear           | 20 EUCBLI-45M  | 1 | piece |
| 2CKA002018A1575 | SCHUKO® socket insert<br>Safety Shutter with<br>Hinged Lid studio white -<br>Busch-art linear   | 20 EUKB-44G    | 1 | piece |
| 2CKA002018A1576 | SCHUKO® socket insert<br>Safety Shutter with<br>Hinged Lid studio white<br>matt - Busch-art linear                                    | 20 EUKB-44M    | 1 | piece |
| 2CKA002018A1578 | SCHUKO® socket insert<br>Safety Shutter with<br>Hinged Lid black matt -<br>Busch-art linear   | 20 EUKB-45M    | 1 | piece |
| 2CKA002017A1909 | Socket insert with<br>earthing pin Safety<br>Shutter with Hinged Lid<br>studio white - Busch-art<br>linear                            | 20-1 MUCBK-44G | 1 | piece |
| 2CKA002017A1910 | Socket insert with<br>earthing pin Safety<br>Shutter with Hinged Lid<br>studio white matt - Busch<br>-art linear                      | 20-1 MUCBK-44M | 1 | piece |
| 2CKA002017A1912 | Socket insert with<br>earthing pin Safety<br>Shutter with Hinged Lid<br>black matt - Busch-art<br>linear                              | 20-1 MUCBK-45M | 1 | piece |
| 2CKA001763A0032 | Sealing Set with Sealing<br>Ring transparent - Busch-<br>art linear   | 20 WD-4X       | 1 | piece |
| 2CKA001710A4141 | Cover plate with legend<br>Symbol "arrows" for<br>Venetian blind, Turn<br>button studio white -<br>Busch-art linear                   | 1740-44G       | 1 | piece |
| 2CKA001710A4142 | Cover plate with legend<br>Symbol "arrows" for<br>Venetian blind, Turn<br>button studio white matt<br>- Busch-art linear              | 1740-44M       | 1 | piece |
| 2CKA001710A4144 | Cover plate with legend<br>Symbol "arrows" for<br>Venetian blind, Turn<br>button black matt - Busch<br>-art linear                    | 1740-45M       | 1 | piece |

|                 |  |                  |   |       |
|-----------------|--|------------------|---|-------|
| 2CKA006599A3052 | Cover plate for Dimmer Turn button with Neon lamp studio white - Busch-art linear                  | 6540-44G-102     | 1 | piece |
| 2CKA006599A3053 | Cover plate for Dimmer Turn button with Neon lamp studio white matt - Busch-art linear             | 6540-44M-102     | 1 | piece |
| 2CKA006599A3055 | Cover plate for Dimmer Turn button with Neon lamp black matt - Busch-art linear                    | 6540-45M-102     | 1 | piece |
| 2CKA006599A3056 | Cover plate for Dimmer Turn button with Neon lamp studio white - Busch-art linear                  | 6540-44G-102-500 | 1 | piece |
| 2CKA006599A3057 | Cover plate for Dimmer Turn button with Neon lamp studio white matt - Busch-art linear             | 6540-44M-102-500 | 1 | piece |
| 2CKA006599A3059 | Cover plate for Dimmer Turn button with Neon lamp black matt - Busch-art linear                    | 6540-45M-102-500 | 1 | piece |
| 2CKA006155A0122 | Cover plate Symbols "up, down, ECO, menu" for Room temperature controller white - Busch-art linear | 6109/03-44G      | 1 | piece |
| 2CKA006155A0123 | Cover plate Symbols "up, down, ECO, menu" for Room temperature controller white - Busch-art linear | 6109/03-44M      | 1 | piece |
| 2CKA006155A0125 | Cover plate Symbols "up, down, ECO, menu" for Room temperature controller black - Busch-art linear | 6109/03-45M      | 1 | piece |
| 2CKA006155A0126 | Cover plate Symbols "up, down, ECO, menu" for Room temperature controller white - Busch-art linear | 6109/03-44G-500  | 1 | piece |
| 2CKA006155A0127 | Cover plate Symbols "up, down, ECO, menu" for Room temperature controller white - Busch-art linear | 6109/03-44M-500  | 1 | piece |
| 2CKA006155A0129 | Cover plate Symbols "up, down, ECO, menu" for Room temperature controller black - Busch-art linear | 6109/03-45M-500  | 1 | piece |
| 2CKA006220A0920 | Cover plate Symbols "up, down, ECO, Power" 2gang studio white - Busch-art linear                   | 6235-44G         | 1 | piece |
| 2CKA006220A0921 | Cover plate Symbols "up, down, ECO, Power" 2gang studio white matt - Busch-art linear              | 6235-44M         | 1 | piece |

|                 |   |               |   |       |
|-----------------|---|---------------|---|-------|
| 2CKA006220A0923 | Cover plate Symbols "up, down, ECO, Power" 2gang black matt - Busch-art linear  | 6235-45M      | 1 | piece |
| 2CKA001710A4206 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white matt - Busch-art linear  | 1794 R-44M    | 1 | piece |
| 2CKA001710A4207 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button studio white - Busch-art linear   | 1794 R-44G    | 1 | piece |
| 2CKA001710A4208 | Cover plate with legend Characters 1 ... 6 for Thermostat Turn button black matt - Busch-art linear   | 1794 R-45M    | 1 | piece |
| 2CKA006430A0426 | Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Room temperature controller Central cover plate studio white - Busch-art linear      | 1794 MDRT-44G | 1 | piece |
| 2CKA006430A0425 | Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Room temperature controller Central cover plate studio white matt - Busch-art linear | 1794 MDRT-44M | 1 | piece |
| 2CKA006430A0427 | Cover Plate, Thermostat Symbols "temp up/down, Power, left, menu, right" 6gang for Room temperature controller Central cover plate black matt - Busch-art linear        | 1794 MDRT-45M | 1 | piece |
| 2CKA006800A3136 | Busch-Watchdog 180 flex Cover plate Movement sensor white - Busch-art linear  | 64764-44G     | 1 | piece |
| 2CKA006800A3137 | Busch-Watchdog 180 flex Cover plate Movement sensor white - Busch-art linear  | 64764-44M     | 1 | piece |
| 2CKA006800A3139 | Busch-Watchdog 180 flex Cover plate Movement sensor black - Busch-art linear  | 64764-45M     | 1 | piece |
| 2CKA006800A3140 | Cover plate Movement sensor white - Busch-art linear  | 64764-44G-500 | 1 | piece |
| 2CKA006800A3141 | Cover plate Movement sensor white - Busch-art linear  | 64764-44M-500 | 1 | piece |
| 2CKA006800A3143 | Cover plate Movement sensor black - Busch-art linear  | 64764-45M-500 | 1 | piece |

|                 |   |                |   |       |
|-----------------|---|----------------|---|-------|
| 2CKA006800A3120 | Busch-Watchdog 180 flex<br>Cover plate Movement<br>sensor white - Busch-art<br>linear   | 64761-44G      | 1 | piece |
| 2CKA006800A3121 | Busch-Watchdog 180 flex<br>Cover plate Movement<br>sensor white - Busch-art<br>linear   | 64761-44M      | 1 | piece |
| 2CKA006800A3123 | Busch-Watchdog 180 flex<br>Cover plate Movement<br>sensor black - Busch-art<br>linear   | 64761-45M      | 1 | piece |
| 2CKA006800A3124 | Busch-Watchdog Cover<br>plate Movement sensor<br>white - Busch-art linear   | 64761-44G-500  | 1 | piece |
| 2CKA006800A3125 | Busch-Watchdog Cover<br>plate Movement sensor<br>white - Busch-art linear   | 64761-44M-500  | 1 | piece |
| 2CKA006800A3127 | Busch-Watchdog Cover<br>plate Movement sensor<br>black - Busch-art linear   | 64761-45M-500  | 1 | piece |
| 2CKA001751A3309 | Rocker with legend DND,<br>MUR with Small<br>Transparent Calotte for<br>Switch/push button, Two<br>-part rocker studio white -<br>Busch-art linear      | 1785/11 K-44G  | 1 | piece |
| 2CKA001751A3310 | Rocker with legend DND,<br>MUR with Small<br>Transparent Calotte for<br>Switch/push button, Two<br>-part rocker studio white<br>matt - Busch-art linear | 1785/11 K-44M  | 1 | piece |
| 2CKA001751A3312 | Rocker with legend DND,<br>MUR with Small<br>Transparent Calotte for<br>Switch/push button, Two<br>-part rocker black matt -<br>Busch-art linear        | 1785/11 K-45M  | 1 | piece |
| 2CKA001751A3401 | Bell push-switch DND /<br>MUR insert DND, MUR and<br>Symbol "bell" Single push<br>button 1P with LED studio<br>white - Busch-art linear                 | 2029/12 UC-44G | 1 | piece |
| 2CKA001751A3402 | Bell push-switch DND /<br>MUR insert DND, MUR and<br>Symbol "bell" Single push<br>button 1P with LED studio<br>white matt - Busch-art<br>linear         | 2029/12 UC-44M | 1 | piece |
| 2CKA001751A3404 | Bell push-switch DND /<br>MUR insert DND, MUR and<br>Symbol "bell" Single push<br>button 1P with LED black<br>matt - Busch-art linear                   | 2029/12 UC-45M | 1 | piece |
| 2CKA001751A3405 | Bell push-switch DND /<br>MUR insert DND, MUR and<br>Symbol "bell" Single push<br>button 1P with LED 1NO<br>studio white - Busch-art<br>linear          | 2029 UC-44G    | 1 | piece |

|                 |   |               |   |       |
|-----------------|---|---------------|---|-------|
| 2CKA001751A3406 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P with LED 1NO studio white matt - Busch-art linear    | 2029 UC-44M   | 1 | piece |
| 2CKA001751A3408 | Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button 1P with LED 1NO black matt - Busch-art linear           | 2029 UC-45M   | 1 | piece |
| 2CKA001710A4240 | Cover plate with legend Card, Symbol "arrows" 2-pole push button 2P with LED Orientation light 1NO studio white - Busch-art linear      | 1792 U-44G    | 1 | piece |
| 2CKA001710A4241 | Cover plate with legend Card, Symbol "arrows" 2-pole push button 2P with LED Orientation light 1NO studio white matt - Busch-art linear | 1792 U-44M    | 1 | piece |
| 2CKA001710A4243 | Cover plate with legend Card, Symbol "arrows" 2-pole push button 2P with LED Orientation light 1NO black matt - Busch-art linear        | 1792 U-45M    | 1 | piece |
| 2CKA001710A4244 | Cover plate with legend Card, Symbol "arrows" for Card switch RFID Hotel card studio white - Busch-art linear                           | 1792 RFID-44G | 1 | piece |
| 2CKA001710A4245 | Cover plate with legend Card, Symbol "arrows" for Card switch RFID Hotel card studio white matt - Busch-art linear                      | 1792 RFID-44M | 1 | piece |
| 2CKA001710A4247 | Cover plate with legend Card, Symbol "arrows" for Card switch RFID Hotel card black matt - Busch-art linear                             | 1792 RFID-45M | 1 | piece |
| 2CKA001751A3313 | Rocker with legend DND, MUR with Small Transparent Calotte for Switch/push button Two-part rocker studio white - Busch-art linear       | 2058-24-44G   | 1 | piece |
| 2CKA001751A3314 | Rocker with legend DND, MUR with Small Transparent Calotte for Switch/push button Two-part rocker studio white matt - Busch-art linear  | 2058-24-44M   | 1 | piece |
| 2CKA001751A3316 | Rocker with legend DND, MUR with Small Transparent Calotte for Switch/push button Two-part rocker black matt - Busch-art linear         | 2058-24-45M   | 1 | piece |

|                 |   |  |   |       |
|-----------------|---|--|---|-------|
| 2CKA001751A3317 | Rocker for Electronic push2570-20-44G<br>button Two-part rocker<br>studio white - Busch-art<br>linear   |  | 1 | piece |
| 2CKA001751A3318 | Rocker for Electronic push2570-20-44M<br>button Two-part rocker<br>studio white matt - Busch<br>-art linear   |  | 1 | piece |
| 2CKA001751A3320 | Rocker for Electronic push2570-20-45M<br>button Two-part rocker<br>black matt - Busch-art<br>linear   |  | 1 | piece |
| 2CKA001751A3321 | Bell push-switch DND / 2059 UC-44G<br>MUR insert DND, MUR and<br>Symbol "bell" 1gang<br>Single push button with<br>LED 1 rocker studio white<br>- Busch-art linear      |  | 1 | piece |
| 2CKA001751A3322 | Bell push-switch DND / 2059 UC-44M<br>MUR insert DND, MUR and<br>Symbol "bell" 1gang<br>Single push button with<br>LED 1 rocker studio white<br>matt - Busch-art linear |  | 1 | piece |
| 2CKA001751A3324 | Bell push-switch DND / 2059 UC-45M<br>MUR insert DND, MUR and<br>Symbol "bell" 1gang<br>Single push button with<br>LED 1 rocker black matt -<br>Busch-art linear        |  | 1 | piece |
| 2CKA001751A3325 | Rocker for Electronic push2570-10-44G<br>button Single rocker<br>studio white - Busch-art<br>linear   |  | 1 | piece |
| 2CKA001751A3326 | Rocker for Electronic push2570-10-44M<br>button Single rocker<br>studio white matt - Busch<br>-art linear   |  | 1 | piece |
| 2CKA001751A3328 | Rocker for Electronic push2570-10-45M<br>button Single rocker black<br>matt - Busch-art linear  |  | 1 | piece |
| 2CKA001751A3329 | Rocker for Electronic push2570-30-44G<br>button Three-part rocker<br>studio white - Busch-art<br>linear   |  | 1 | piece |
| 2CKA001751A3330 | Rocker for Electronic push2570-30-44M<br>button Three-part rocker<br>studio white matt - Busch<br>-art linear   |  | 1 | piece |
| 2CKA001751A3332 | Rocker for Electronic push2570-30-45M<br>button Three-part rocker<br>black matt - Busch-art<br>linear   |  | 1 | piece |
| 2CKA001751A3413 | Rocker for Smart switch 6735 BT-44G<br>Single rocker studio white<br>- Busch-art linear   |  | 1 | piece |
| 2CKA001751A3414 | Rocker for Smart switch 6735 BT-44M<br>Single rocker studio white<br>matt - Busch-art linear  |  | 1 | piece |
| 2CKA001751A3416 | Rocker for Smart switch 6735 BT-45M<br>Single rocker black matt -<br>Busch-art linear   |  | 1 | piece |

|                 |   |                  |   |       |
|-----------------|---|------------------|---|-------|
| 2CKA006730A0166 | Rocker for Smart switch<br>Two-part rocker studio<br>white - Busch-art linear   | 6736 FoH-44G     | 1 | piece |
| 2CKA006730A0167 | Rocker for Smart switch<br>Two-part rocker studio<br>white matt - Busch-art<br>linear                                   | 6736 FoH-44M     | 1 | piece |
| 2CKA006730A0169 | Rocker for Smart switch<br>Two-part rocker black<br>matt - Busch-art linear   | 6736 FoH-45M     | 1 | piece |
| 2CKA001710A4137 | Cover plate with legend<br>Loudspeaker Turn button<br>studio white - Busch-art<br>linear                                | 1740 DR/03-44G   | 1 | piece |
| 2CKA001710A4138 | Cover plate with legend<br>Loudspeaker Turn button<br>studio white matt - Busch<br>-art linear                          | 1740 DR/03-44M   | 1 | piece |
| 2CKA001710A4140 | Cover plate with legend<br>Loudspeaker Turn button<br>black matt - Busch-art<br>linear                                  | 1740 DR/03-45M   | 1 | piece |
| 2CKA001710A4145 | Cover plate Symbol "2-1-3"<br>for Level switch, Turn<br>button studio white -<br>Busch-art linear                       | 1740 DRL-44G-503 | 1 | piece |
| 2CKA001710A4146 | Cover plate Symbol "2-1-3"<br>for Level switch, Turn<br>button studio white matt<br>- Busch-art linear                  | 1740 DRL-44M-503 | 1 | piece |
| 2CKA001710A4148 | Cover plate Symbol "2-1-3"<br>for Level switch, Turn<br>button black matt - Busch<br>-art linear                        | 1740 DRL-45M-503 | 1 | piece |
| 2CKA001753A9978 | Cover plate with legend<br>0 ... 120 Min for Time<br>switch, Turning handle<br>studio white - Busch-art<br>linear       | 1771-44G-103     | 1 | piece |
| 2CKA001753A9979 | Cover plate with legend<br>0 ... 120 Min for Time<br>switch, Turning handle<br>studio white matt - Busch<br>-art linear | 1771-44M-103     | 1 | piece |
| 2CKA001753A9981 | Cover plate with legend<br>0 ... 120 Min for Time<br>switch, Turning handle<br>black matt - Busch-art<br>linear         | 1771-45M-103     | 1 | piece |
| 2CKA001753A9982 | Cover plate with legend<br>0 ... 15 Min for Time<br>switch, Turning handle<br>studio white - Busch-art<br>linear        | 1770-44G-103     | 1 | piece |
| 2CKA001753A9983 | Cover plate with legend<br>0 ... 15 Min for Time<br>switch, Turning handle<br>studio white matt - Busch<br>-art linear  | 1770-44M-103     | 1 | piece |

|                 |  |                |   |       |
|-----------------|--|----------------|---|-------|
| 2CKA001753A9985 | Cover plate with legend<br>0 ... 15 Min for Time<br>switch, Turning handle<br>black matt - Busch-art<br>linear               | 1770-45M-103   | 1 | piece |
| 2CKA001710A4149 | Cover plate with legend<br>Symbol "0-1-2-3" for Level<br>switch, Turn button<br>studio white - Busch-art<br>linear           | 2542 DR/01-44G | 1 | piece |
| 2CKA001710A4150 | Cover plate with legend<br>Symbol "0-1-2-3" for Level<br>switch, Turn button<br>studio white matt - Busch<br>-art linear     | 2542 DR/01-44M | 1 | piece |
| 2CKA001710A4152 | Cover plate with legend<br>Symbol "0-1-2-3" for Level<br>switch, Turn button black<br>matt - Busch-art linear                | 2542 DR/01-45M | 1 | piece |
| 2CKA001710A4157 | Cover plate with legend<br>Symbol "arrows" or "0 - 1"<br>for Venetian blind, Key<br>studio white - Busch-art<br>linear       | 1755 SL/PZ-44G | 1 | piece |
| 2CKA001710A4158 | Cover plate with legend<br>Symbol "arrows" or "0 - 1"<br>for Venetian blind, Key<br>studio white matt - Busch<br>-art linear | 1755 SL/PZ-44M | 1 | piece |
| 2CKA001710A4160 | Cover plate with legend<br>Symbol "arrows" or "0 - 1"<br>for Venetian blind, Key<br>black matt - Busch-art<br>linear         | 1755 SL/PZ-45M | 1 | piece |
| 2CKA001710A4153 | Cover plate with legend<br>Symbol "1-2-3" for Level<br>switch, Turn button<br>studio white - Busch-art<br>linear             | 2542 DR/02-44G | 1 | piece |
| 2CKA001710A4154 | Cover plate with legend<br>Symbol "1-2-3" for Level<br>switch, Turn button<br>studio white matt - Busch<br>-art linear       | 2542 DR/02-44M | 1 | piece |
| 2CKA001710A4156 | Cover plate with legend<br>Symbol "1-2-3" for Level<br>switch, Turn button black<br>matt - Busch-art linear                  | 2542 DR/02-45M | 1 | piece |
| 2CKA008200A0285 | Cover plate with legend<br>Busch-Radio Radio white -<br>Busch-art linear   | 8252-44G-101   | 1 | piece |
| 2CKA008200A0286 | Cover plate with legend<br>Busch-Radio Radio white -<br>Busch-art linear   | 8252-44M-101   | 1 | piece |
| 2CKA008200A0288 | Cover plate with legend<br>Busch-Radio Radio black -<br>Busch-art linear   | 8252-45M-101   | 1 | piece |
| 2CKA008200A0289 | Cover plate Loudspeaker<br>white - Busch-art linear  | 8253-44G       | 1 | piece |
| 2CKA008200A0291 | Cover plate Loudspeaker<br>black - Busch-art linear  | 8253-45G       | 1 | piece |

|                 |  |             |   |       |
|-----------------|--|-------------|---|-------|
| 2CKA006430A0450 | Cover plate with legend<br>Symbols "play, up, down,<br>ok" for Time switch, Room<br>temperature controller,<br>CO2-sensor Central cover<br>plate studio white - Busch<br>-art linear     | 6435-44G    | 1 | piece |
| 2CKA006430A0451 | Cover plate with legend<br>Symbols "play, up, down,<br>ok" for Time switch, Room<br>temperature controller,<br>CO2-sensor Central cover<br>plate studio white matt -<br>Busch-art linear | 6435-44M    | 1 | piece |
| 2CKA006430A0453 | Cover plate with legend<br>Symbols "play, up, down,<br>ok" for Time switch, Room<br>temperature controller,<br>CO2-sensor Central cover<br>plate black matt - Busch-<br>art linear       | 6435-45M    | 1 | piece |
| 2CKA006220A0924 | Rocker 1gang studio<br>white - Busch-art linear  | 6230-10-44G | 1 | piece |
| 2CKA006220A0925 | Rocker 1gang studio<br>white matt - Busch-art<br>linear  | 6230-10-44M | 1 | piece |
| 2CKA006220A0927 | Rocker 1gang black matt -<br>Busch-art linear  | 6230-10-45M | 1 | piece |
| 2CKA006220A0928 | Rocker Symbol "light"<br>1gang studio white -<br>Busch-art linear  | 6231-10-44G | 1 | piece |
| 2CKA006220A0929 | Rocker Symbol "light"<br>1gang studio white matt -<br>Busch-art linear   | 6231-10-44M | 1 | piece |
| 2CKA006220A0931 | Rocker Symbol "light"<br>1gang black matt - Busch-<br>art linear   | 6231-10-45M | 1 | piece |
| 2CKA006220A0932 | Rocker Symbol "dimming"<br>1gang studio white -<br>Busch-art linear  | 6234-10-44G | 1 | piece |
| 2CKA006220A0933 | Rocker Symbol "dimming"<br>1gang studio white matt -<br>Busch-art linear   | 6234-10-44M | 1 | piece |
| 2CKA006220A0935 | Rocker Symbol "dimming"<br>1gang black matt - Busch-<br>art linear   | 6234-10-45M | 1 | piece |
| 2CKA006220A0936 | Rocker Symbol "venetian<br>blind" 1gang studio white<br>- Busch-art linear   | 6232-10-44G | 1 | piece |
| 2CKA006220A0937 | Rocker Symbol "venetian<br>blind" 1gang studio white<br>matt - Busch-art linear  | 6232-10-44M | 1 | piece |
| 2CKA006220A0939 | Rocker Symbol "venetian<br>blind" 1gang black matt -<br>Busch-art linear   | 6232-10-45M | 1 | piece |
| 2CKA006220A0940 | Rocker Symbol "scene"<br>1gang studio white -<br>Busch-art linear  | 6233-10-44G | 1 | piece |

|                 |   |             |   |       |
|-----------------|---|-------------|---|-------|
| 2CKA006220A0941 | Rocker Symbol "scene"<br>1gang studio white matt -<br>Busch-art linear          | 6233-10-44M | 1 | piece |
| 2CKA006220A0943 | Rocker Symbol "scene"<br>1gang black matt - Busch-<br>art linear                | 6233-10-45M | 1 | piece |
| 2CKA006220A0944 | Rocker 2gang studio<br>white - Busch-art linear                                 | 6230-20-44G | 1 | piece |
| 2CKA006220A0945 | Rocker 2gang studio<br>white matt - Busch-art<br>linear                         | 6230-20-44M | 1 | piece |
| 2CKA006220A0947 | Rocker 2gang black matt -<br>Busch-art linear                                   | 6230-20-45M | 1 | piece |
| 2CKA006220A0948 | Rocker Symbol "light"<br>2gang studio white -<br>Busch-art linear               | 6231-21-44G | 1 | piece |
| 2CKA006220A0949 | Rocker Symbol "light"<br>2gang studio white matt -<br>Busch-art linear          | 6231-21-44M | 1 | piece |
| 2CKA006220A0951 | Rocker Symbol "light"<br>2gang black matt - Busch-<br>art linear                | 6231-21-45M | 1 | piece |
| 2CKA006220A0952 | Rocker Symbol "light"<br>2gang studio white -<br>Busch-art linear               | 6231-22-44G | 1 | piece |
| 2CKA006220A0953 | Rocker Symbol "light"<br>2gang studio white matt -<br>Busch-art linear          | 6231-22-44M | 1 | piece |
| 2CKA006220A0955 | Rocker Symbol "light"<br>2gang black matt - Busch-<br>art linear                | 6231-22-45M | 1 | piece |
| 2CKA006220A0956 | Rocker Symbol "dimming"<br>2gang studio white -<br>Busch-art linear             | 6234-21-44G | 1 | piece |
| 2CKA006220A0957 | Rocker Symbol "dimming"<br>2gang studio white matt -<br>Busch-art linear        | 6234-21-44M | 1 | piece |
| 2CKA006220A0959 | Rocker Symbol "dimming"<br>2gang black matt - Busch-<br>art linear              | 6234-21-45M | 1 | piece |
| 2CKA006220A0960 | Rocker Symbol "dimming"<br>2gang studio white -<br>Busch-art linear             | 6234-22-44G | 1 | piece |
| 2CKA006220A0961 | Rocker Symbol "dimming"<br>2gang studio white matt -<br>Busch-art linear        | 6234-22-44M | 1 | piece |
| 2CKA006220A0963 | Rocker Symbol "dimming"<br>2gang black matt - Busch-<br>art linear              | 6234-22-45M | 1 | piece |
| 2CKA006220A0964 | Rocker Symbol "venetian<br>blind" 2gang studio white<br>- Busch-art linear      | 6232-20-44G | 1 | piece |
| 2CKA006220A0965 | Rocker Symbol "venetian<br>blind" 2gang studio white<br>matt - Busch-art linear | 6232-20-44M | 1 | piece |
| 2CKA006220A0967 | Rocker Symbol "venetian<br>blind" 2gang black matt -<br>Busch-art linear        | 6232-20-45M | 1 | piece |

|                 |  |                  |   |       |
|-----------------|--|------------------|---|-------|
| 2CKA006220A0968 | Rocker Symbol "scene"<br>2gang studio white -<br>Busch-art linear                  | 6233-21-44G      | 1 | piece |
| 2CKA006220A0969 | Rocker Symbol "scene"<br>2gang studio white matt -<br>Busch-art linear             | 6233-21-44M      | 1 | piece |
| 2CKA006220A0971 | Rocker Symbol "scene"<br>2gang black matt - Busch-<br>art linear                   | 6233-21-45M      | 1 | piece |
| 2CKA006220A0972 | Rocker Symbol "scene"<br>2gang studio white -<br>Busch-art linear                  | 6233-22-44G      | 1 | piece |
| 2CKA006220A0973 | Rocker Symbol "scene"<br>2gang studio white matt -<br>Busch-art linear             | 6233-22-44M      | 1 | piece |
| 2CKA006220A0975 | Rocker Symbol "scene"<br>2gang black matt - Busch-<br>art linear                   | 6233-22-45M      | 1 | piece |
| 2CKA006220A0976 | Rocker Symbols "music<br>control" 2gang studio<br>white - Busch-art linear         | 6237-21-44G      | 1 | piece |
| 2CKA006220A0977 | Rocker Symbols "music<br>control" 2gang studio<br>white matt - Busch-art<br>linear | 6237-21-44M      | 1 | piece |
| 2CKA006220A0979 | Rocker Symbols "music<br>control" 2gang black matt<br>- Busch-art linear           | 6237-21-45M      | 1 | piece |
| 2CKA006220A0980 | Rocker Symbols "music<br>control" 2gang studio<br>white - Busch-art linear         | 6237-22-44G      | 1 | piece |
| 2CKA006220A0981 | Rocker Symbols "music<br>control" 2gang studio<br>white matt - Busch-art<br>linear | 6237-22-44M      | 1 | piece |
| 2CKA006220A0983 | Rocker Symbols "music<br>control" 2gang black matt<br>- Busch-art linear           | 6237-22-45M      | 1 | piece |
| 2CKA006200A0298 | Cover plate Movement<br>sensor Wireless white -<br>Busch-art linear                | 62762-44G-WL     | 1 | piece |
| 2CKA006200A0299 | Cover plate Movement<br>sensor Wireless white -<br>Busch-art linear                | 62762-44M-WL     | 1 | piece |
| 2CKA006200A0301 | Cover plate Movement<br>sensor Wireless black -<br>Busch-art linear                | 62762-45M-WL     | 1 | piece |
| 2CKA006200A0302 | Cover plate Movement<br>sensor Wireless white -<br>Busch-art linear                | 62762-44G-WL-500 | 1 | piece |
| 2CKA006200A0303 | Cover plate Movement<br>sensor Wireless white -<br>Busch-art linear                | 62762-44M-WL-500 | 1 | piece |
| 2CKA006200A0305 | Cover plate Movement<br>sensor Wireless black -<br>Busch-art linear                | 62762-45M-WL-500 | 1 | piece |

|                 |  |                  |   |       |
|-----------------|--|------------------|---|-------|
| 2CKA006800A3128 | Busch-Watchdog 180 flex<br>Cover plate Movement<br>sensor white - Busch-art<br>linear                                      | 64762-44G        | 1 | piece |
| 2CKA006800A3129 | Busch-Watchdog 180 flex<br>Cover plate Movement<br>sensor white - Busch-art<br>linear                                      | 64762-44M        | 1 | piece |
| 2CKA006800A3131 | Busch-Watchdog 180 flex<br>Cover plate Movement<br>sensor black - Busch-art<br>linear                                      | 64762-45M        | 1 | piece |
| 2CKA006800A3132 | Busch-Watchdog Cover<br>plate Movement sensor<br>white - Busch-art linear  | 64762-44G-500    | 1 | piece |
| 2CKA006800A3133 | Busch-Watchdog Cover<br>plate Movement sensor<br>white - Busch-art linear  | 64762-44M-500    | 1 | piece |
| 2CKA006800A3135 | Busch-Watchdog Cover<br>plate Movement sensor<br>black - Busch-art linear  | 64762-45M-500    | 1 | piece |
| 2CKA006200A0307 | Cover plate Enrolment<br>device Wireless white -<br>Busch-art linear   | 62764-44G-WL     | 1 | piece |
| 2CKA006200A0308 | Cover plate Enrolment<br>device Wireless white -<br>Busch-art linear   | 62764-44M-WL     | 1 | piece |
| 2CKA006200A0310 | Cover plate Enrolment<br>device Wireless black -<br>Busch-art linear   | 62764-45M-WL     | 1 | piece |
| 2CKA006200A0311 | Cover plate Enrolment<br>device Wireless white -<br>Busch-art linear   | 62764-44G-WL-500 | 1 | piece |
| 2CKA006200A0312 | Cover plate Enrolment<br>device Wireless white -<br>Busch-art linear   | 62764-44M-WL-500 | 1 | piece |
| 2CKA006200A0314 | Cover plate Enrolment<br>device Wireless black -<br>Busch-art linear   | 62764-45M-WL-500 | 1 | piece |
| 2CKA006800A3144 | Busch-Comfort switch®<br>flex Control Element<br>Movement sensor with<br>LED Orientation light<br>white - Busch-art linear | 64765-44G        | 1 | piece |
| 2CKA006800A3145 | Busch-Comfort switch®<br>flex Control Element<br>Movement sensor with<br>LED Orientation light<br>white - Busch-art linear | 64765-44M        | 1 | piece |
| 2CKA006800A3147 | Busch-Comfort switch®<br>flex Control Element<br>Movement sensor with<br>LED Orientation light<br>black - Busch-art linear | 64765-45M        | 1 | piece |
| 2CKA001710A4170 | Intermediate Ring for<br>cover plates Busch-<br>Balance® SI 1-gang white -<br>Busch-art linear                             | 1747 BSI-44G     | 1 | piece |

|                 |  |              |   |       |
|-----------------|--|--------------|---|-------|
| 2CKA001710A4171 | Intermediate Ring for cover plates Busch-Balance® SI 1-gang white - Busch-art linear                                   | 1747 BSI-44M | 1 | piece |
| 2CKA001710A4173 | Intermediate Ring for cover plates Busch-Balance® SI 1-gang black - Busch-art linear                                   | 1747 BSI-45M | 1 | piece |
| 2CKA001719A0179 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring white - Busch-art linear | 2518-WD-44G  | 1 | piece |
| 2CKA001719A0180 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring white - Busch-art linear | 2518-WD-44M  | 1 | piece |
| 2CKA001719A0182 | Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1-gang with Sealing Ring black - Busch-art linear | 2518-WD-45M  | 1 | piece |
| 2CKA001710A4174 | Cover plate 50x50 mm for 1746/10-44G data connection housing white - Busch-art linear                                  |              | 1 | piece |
| 2CKA001710A4175 | Cover plate 50x50 mm for 1746/10-44M data connection housing white - Busch-art linear                                  |              | 1 | piece |
| 2CKA001710A4177 | Cover plate 50x50 mm for 1746/10-45M data connection housing black - Busch-art linear                                  |              | 1 | piece |
| 2CKA001710A4178 | Cover plate 50x50 mm for 1746/10-44G-500 data connection housing white - Busch-art linear                              |              | 1 | piece |
| 2CKA001710A4179 | Cover plate 50x50 mm for 1746/10-44M-500 data connection housing white - Busch-art linear                              |              | 1 | piece |
| 2CKA001710A4181 | Cover plate 50x50 mm for 1746/10-45M-500 data connection housing black - Busch-art linear                              |              | 1 | piece |
| 2CKA001753A9917 | Cover plate 50x50 mm with Hinged Lid for data connection housing white - Busch-art linear                              | 1746-44G     | 1 | piece |
| 2CKA001753A9918 | Cover plate 50x50 mm with Hinged Lid for data connection housing white - Busch-art linear                              | 1746-44M     | 1 | piece |
| 2CKA001753A9920 | Cover plate 50x50 mm with Hinged Lid for data connection housing black - Busch-art linear                              | 1746-45M     | 1 | piece |
| 2CKA001710A4211 | Cover plate for Blind cap 11742-44G -gang with Mounting plate white - Busch-art linear                                 |              | 1 | piece |
| 2CKA001710A4212 | Cover plate for Blind cap 11742-44M -gang with Mounting plate white - Busch-art linear                                 |              | 1 | piece |

|                 |   |              |   |       |
|-----------------|---|--------------|---|-------|
| 2CKA001710A4214 | Cover plate for Blind cap 11742-45M<br>-gang with Mounting<br>plate black - Busch-art<br>linear                           |              | 1 | piece |
| 2CKA001710A4215 | Cover plate for Blind cap 11742-44G-500<br>-gang with Mounting<br>plate white - Busch-art<br>linear                       |              | 1 | piece |
| 2CKA001710A4216 | Cover plate for Blind cap 11742-44M-500<br>-gang with Mounting<br>plate white - Busch-art<br>linear                       |              | 1 | piece |
| 2CKA001710A4218 | Cover plate for Blind cap 11742-45M-500<br>-gang with Mounting<br>plate black - Busch-art<br>linear                       |              | 1 | piece |
| 2CKA001710A4248 | Cover plate for Cable<br>outlet 1-gang with<br>Mounting plate; 3-pole<br>screw terminal block<br>white - Busch-art linear | 1749-44G     | 1 | piece |
| 2CKA001710A4249 | Cover plate for Cable<br>outlet 1-gang with<br>Mounting plate; 3-pole<br>screw terminal block<br>white - Busch-art linear | 1749-44M     | 1 | piece |
| 2CKA001710A4251 | Cover plate for Cable<br>outlet 1-gang with<br>Mounting plate; 3-pole<br>screw terminal block<br>black - Busch-art linear | 1749-45M     | 1 | piece |
| 2CKA001710A4162 | Cover plate D-Sub 15-pole 1766-44G<br>1 gang white - Busch-art<br>linear  |              | 1 | piece |
| 2CKA001710A4163 | Cover plate D-Sub 15-pole 1766-44M<br>1 gang white - Busch-art<br>linear  |              | 1 | piece |
| 2CKA001710A4165 | Cover plate D-Sub 15-pole 1766-45M<br>1 gang black - Busch-art<br>linear  |              | 1 | piece |
| 2CKA001710A4166 | Cover plate DSub15Pole 1 1766-44G-500<br>gang white - Busch-art<br>linear   |              | 1 | piece |
| 2CKA001710A4167 | Cover plate DSub15Pole 1 1766-44M-500<br>gang white - Busch-art<br>linear   |              | 1 | piece |
| 2CKA001710A4169 | Cover plate DSub15Pole 1 1766-45M-500<br>gang black - Busch-art<br>linear   |              | 1 | piece |
| 2CKA001724A4432 | Cover plate SAT 3 gang<br>white - Busch-art linear  | 1743-44G     | 1 | piece |
| 2CKA001724A4433 | Cover plate SAT 3 gang<br>white - Busch-art linear  | 1743-44M     | 1 | piece |
| 2CKA001724A4435 | Cover plate SAT 3 gang<br>black - Busch-art linear  | 1743-45M     | 1 | piece |
| 2CKA001724A4436 | Cover plate TV / Radio /<br>SAT 3 gang studio white -<br>Busch-art linear   | 1743-44G-500 | 1 | piece |

|                 |  |                 |   |       |
|-----------------|--|-----------------|---|-------|
| 2CKA001724A4437 | Cover plate TV / Radio / SAT 3 gang studio white matt - Busch-art linear                     | 1743-44M-500    | 1 | piece |
| 2CKA001724A4439 | Cover plate TV / Radio / SAT 3 gang black matt - Busch-art linear                            | 1743-45M-500    | 1 | piece |
| 2CKA001724A4440 | Cover plate SAT 4 gang white - Busch-art linear  | 1743/10-04-44G  | 1 | piece |
| 2CKA001724A4441 | Cover plate SAT 4 gang white - Busch-art linear  | 1743/10-04-44M  | 1 | piece |
| 2CKA001724A4443 | Cover plate SAT 4 gang black - Busch-art linear  | 1743/10-04-45M  | 1 | piece |
| 2CKA001710A4219 | Cover plate with labelling field for data connection housing 1 gang white - Busch-art linear | 1803-44G        | 1 | piece |
| 2CKA001710A4220 | Cover plate with labelling field for data connection housing 1 gang white - Busch-art linear | 1803-44M        | 1 | piece |
| 2CKA001710A4222 | Cover plate with labelling field for data connection housing 1 gang black - Busch-art linear | 1803-45M        | 1 | piece |
| 2CKA001710A4223 | Cover plate with labelling field for data connection housing 1 gang white - Busch-art linear | 1803-44G-500    | 1 | piece |
| 2CKA001710A4224 | Cover plate with labelling field for data connection housing 1 gang white - Busch-art linear | 1803-44M-500    | 1 | piece |
| 2CKA001710A4226 | Cover plate with labelling field for data connection housing 1 gang black - Busch-art linear | 1803-45M-500    | 1 | piece |
| 2CKA001710A4227 | Cover plate with labelling field for data connection housing 2 gang white - Busch-art linear | 1803-02-44G     | 1 | piece |
| 2CKA001710A4228 | Cover plate with labelling field for data connection housing 2 gang white - Busch-art linear | 1803-02-44M     | 1 | piece |
| 2CKA001710A4230 | Cover plate with labelling field for data connection housing 2 gang black - Busch-art linear | 1803-02-45M     | 1 | piece |
| 2CKA001710A4231 | Cover plate with labelling field for data connection housing 2 gang white - Busch-art linear | 1803-02-44G-500 | 1 | piece |
| 2CKA001710A4232 | Cover plate with labelling field for data connection housing 2 gang white - Busch-art linear | 1803-02-44M-500 | 1 | piece |
| 2CKA001710A4234 | Cover plate with labelling field for data connection housing 2 gang black - Busch-art linear | 1803-02-45M-500 | 1 | piece |

|                 |   |                 |   |       |
|-----------------|---|-----------------|---|-------|
| 2CKA001724A4444 | Cover plate Pilot devices 12533-44G gang white - Busch-art linear                     |                 | 1 | piece |
| 2CKA001724A4445 | Cover plate Pilot devices 12533-44M gang white - Busch-art linear                     |                 | 1 | piece |
| 2CKA001724A4447 | Cover plate Pilot devices 12533-45M gang black - Busch-art linear                     |                 | 1 | piece |
| 2CKA001724A4455 | Cover plate with labelling field for data connection housing white - Busch-art linear | 1758-44G        | 1 | piece |
| 2CKA001724A4456 | Cover plate with labelling field for data connection housing white - Busch-art linear | 1758-44M        | 1 | piece |
| 2CKA001724A4458 | Cover plate with labelling field for data connection housing black - Busch-art linear | 1758-45M        | 1 | piece |
| 2CKA001753A9922 | Cover plate Keystone 1 gang white - Busch-art linear                                  | 2561-44G        | 1 | piece |
| 2CKA001753A9923 | Cover plate Keystone 1 gang white - Busch-art linear                                  | 2561-44M        | 1 | piece |
| 2CKA001753A9925 | Cover plate Keystone 1 gang black - Busch-art linear                                  | 2561-45M        | 1 | piece |
| 2CKA001710A4235 | Cover plate with labelling field Keystone 2 gang white - Busch-art linear             | 1800-44G        | 1 | piece |
| 2CKA001710A4236 | Cover plate with labelling field Keystone 2 gang white - Busch-art linear             | 1800-44M        | 1 | piece |
| 2CKA001710A4238 | Cover plate with labelling field Keystone 2 gang black - Busch-art linear             | 1800-45M        | 1 | piece |
| 2CKA001753A9926 | Cover plate Keystone 2 gang white - Busch-art linear                                  | 2561-02-44G     | 1 | piece |
| 2CKA001753A9927 | Cover plate Keystone 2 gang white - Busch-art linear                                  | 2561-02-44M     | 1 | piece |
| 2CKA001753A9929 | Cover plate Keystone 2 gang black - Busch-art linear                                  | 2561-02-45M     | 1 | piece |
| 2CKA001724A4448 | Cover plate XLR 1 gang white - Busch-art linear                                       | 2553-44G        | 1 | piece |
| 2CKA001724A4449 | Cover plate XLR 1 gang white - Busch-art linear                                       | 2553-44M        | 1 | piece |
| 2CKA001724A4451 | Cover plate XLR 1 gang black - Busch-art linear                                       | 2553-45M        | 1 | piece |
| 2CKA001582A0441 | Handicapped toilet signal set Busch-Infoline® studio white - Busch-art linear         | 1510 UC-44G-101 | 1 | piece |

|                 |  |                   |   |       |
|-----------------|--|-------------------|---|-------|
| 2CKA001582A0453 | Handicapped toilet signal 1510 UJ-44G set Busch-Infoline® with storage battery buffering studio white - Busch-art linear |                   | 1 | piece |
| 2CKA001582A0443 | Cover plate Busch-Infoline® Alarm studio white - Busch-art linear  | 1573 CN-44G       | 1 | piece |
| 2CKA001582A0445 | Cover plate with labelling field Busch-Infoline® Push button 1 gang studio white - Busch-art linear                      | 1571 CN-44G       | 1 | piece |
| 2CKA001582A0447 | Cover plate with labelling field Busch-Infoline® Push button / Clear 1 gang studio white - Busch-art linear              | 1572 CN-44G       | 1 | piece |
| 2CKA001582A0449 | Cover plate with labelling field Busch-Infoline® studio white - Busch-art linear   | 1575 CN-44G       | 1 | piece |
| 2CKA001582A0451 | Cover plate Busch-Infoline® studio white - Busch-art linear  | 1576 CN-44G       | 1 | piece |
| 2CKA001582A0454 | Cover plate Busch-Infoline® telephone connector boxes (VDo) white - Busch-art linear                                     | 1745-44G          | 1 | piece |
| 2CKA001753A0244 | Insert Busch-Infolicht® LED / White studio white - Busch-art linear  | 1756 U-44G        | 1 | piece |
| 2CKA001753A0245 | Insert Busch-Infolicht® LED / White studio white matt - Busch-art linear   | 1756 U-44M        | 1 | piece |
| 2CKA001753A0247 | Insert Busch-Infolicht® LED / White black matt - Busch-art linear  | 1756 U-45M        | 1 | piece |
| 2CKA006115A0509 | Keypad KNX (TP)  | KK/U4.70.11       | 1 | piece |
| 2CKA006115A0510 | Keypad white - Trevion   | KK/U4.70.1        | 1 | piece |
| 2TMA310010B0006 | Touch Display 1gang Twisted Pair Wiring glass black - Busch-art linear   | SD/U12.70.11-4015 | 1 | piece |
| 2TMA310011B0004 | Touch Display 2.4 in "glassSD/U12.70.1-4015 black - Trevion  |                   | 1 | piece |
| 2CKA006199A0518 | Cover plate None white - Busch-art linear  | LFW/A.0.70.11-CKL | 1 | piece |
| 2CKA006199A0519 | Cover plate None studio white - Trevion  | LFW/A.0.70.1-CKL  | 1 | piece |
| 2CKA006199A0024 | Cover plate None studio white - Busch-art linear   | LFW/A.0.70.11-CK  | 1 | piece |
| 2CKA006199A0025 | Cover plate None studio white - Trevion  | LFW/A.0.70.1-CK   | 1 | piece |
| 2CKA006199A0026 | Cover plate studio white - Busch-art linear  | LFW/A.1.70.11-44G | 1 | piece |
| 2CKA006199A0027 | Cover plate studio white - Busch-art linear  | LFW/A.2.70.11-44G | 1 | piece |
| 2CKA006199A0028 | Cover plate studio white - Busch-art linear  | LFW/A.3.70.11-44G | 1 | piece |

|                 |  |                    |   |       |
|-----------------|--|--------------------|---|-------|
| 2CKA006199A0029 | Cover plate studio white - LFW/A.4.70.11-44G<br>Busch-art linear                                 |                    | 1 | piece |
| 2CKA006199A0030 | Cover plate Symbol "light" LFB/A.1.70.11-44G<br>studio white - Busch-art<br>linear               |                    | 1 | piece |
| 2CKA006199A0031 | Cover plate Symbol<br>"venetian blind" studio<br>white - Busch-art linear                        | LFJ/A.1.70.11-44G  | 1 | piece |
| 2CKA006199A0032 | Cover plate Symbol<br>"scene" studio white -<br>Busch-art linear                                 | LFS/A.1.70.11-44G  | 1 | piece |
| 2CKA006199A0378 | Cover plate Symbol<br>"dimming" studio white -<br>Busch-art linear                               | LFDW/A.1.70.11-44G | 1 | piece |
| 2CKA006199A0379 | Cover plate Symbol<br>"venetian blind" studio<br>white - Busch-art linear                        | LFJW/A.1.70.11-44G | 1 | piece |
| 2CKA006199A0380 | Cover plate Symbol<br>"arrows" studio white -<br>Busch-art linear                                | LFAW/A.1.70.11-44G | 1 | piece |
| 2CKA006199A0381 | Cover plate Symbol "light" LFBT/A.2.70.11-44G<br>studio white - Busch-art<br>linear              |                    | 1 | piece |
| 2CKA006199A0382 | Cover plate Symbol<br>"venetian blind" studio<br>white - Busch-art linear                        | LFJT/A.2.70.11-44G | 1 | piece |
| 2CKA006199A0383 | Cover plate Symbol<br>"scene" studio white -<br>Busch-art linear                                 | LFST/A.2.70.11-44G | 1 | piece |
| 2CKA006199A0384 | Cover plate Symbol<br>"arrows/venetian blind"<br>and "dimmer" studio<br>white - Busch-art linear | LFDW/A.2.70.11-44G | 1 | piece |
| 2CKA006199A0385 | Cover plate Symbol<br>"arrows" studio white -<br>Busch-art linear                                | LFAW/A.2.70.11-44G | 1 | piece |
| 2CKA006199A0386 | Cover plate Symbols<br>"music control" studio<br>white - Busch-art linear                        | LFMW/A.4.70.11-44G | 1 | piece |
| 2CKA006199A0387 | Cover plate studio white<br>matt - Busch-art linear  | LFW/A.1.70.11-44M  | 1 | piece |
| 2CKA006199A0388 | Cover plate studio white<br>matt - Busch-art linear  | LFW/A.2.70.11-44M  | 1 | piece |
| 2CKA006199A0389 | Cover plate studio white<br>matt - Busch-art linear  | LFW/A.3.70.11-44M  | 1 | piece |
| 2CKA006199A0390 | Cover plate studio white<br>matt - Busch-art linear  | LFW/A.4.70.11-44M  | 1 | piece |
| 2CKA006199A0391 | Cover plate Symbol "light" LFB/A.1.70.11-44M<br>studio white matt - Busch<br>-art linear         |                    | 1 | piece |
| 2CKA006199A0392 | Cover plate Symbol<br>"venetian blind" studio<br>white matt - Busch-art<br>linear                | LFJ/A.1.70.11-44M  | 1 | piece |
| 2CKA006199A0393 | Cover plate Symbol<br>"scene" studio white matt<br>- Busch-art linear                            | LFS/A.1.70.11-44M  | 1 | piece |

|                 |  |                    |   |       |
|-----------------|--|--------------------|---|-------|
| 2CKA006199A0394 | Cover plate Symbol "dimming" studio white matt - Busch-art linear                            | LFDW/A.1.70.11-44M | 1 | piece |
| 2CKA006199A0395 | Cover plate Symbol "venetian blind" studio white matt - Busch-art linear                     | LFJW/A.1.70.11-44M | 1 | piece |
| 2CKA006199A0396 | Cover plate Symbol "arrows" studio white matt - Busch-art linear                             | LEAW/A.1.70.11-44M | 1 | piece |
| 2CKA006199A0397 | Cover plate Symbol "light" LFBT/A.2.70.11-44M studio white matt - Busch-art linear           | LFBT/A.2.70.11-44M | 1 | piece |
| 2CKA006199A0398 | Cover plate Symbol "venetian blind" studio white matt - Busch-art linear                     | LFJT/A.2.70.11-44M | 1 | piece |
| 2CKA006199A0399 | Cover plate Symbol "scene" studio white matt - Busch-art linear                              | LFST/A.2.70.11-44M | 1 | piece |
| 2CKA006199A0400 | Cover plate Symbol "arrows/venetian blind" and "dimmer" studio white matt - Busch-art linear | LFDW/A.2.70.11-44M | 1 | piece |
| 2CKA006199A0401 | Cover plate Symbol "arrows" studio white matt - Busch-art linear                             | LEAW/A.2.70.11-44M | 1 | piece |
| 2CKA006199A0402 | Cover plate Symbols "music control" studio white matt - Busch-art linear                     | LFMW/A.4.70.11-44M | 1 | piece |
| 2CKA006199A0419 | Cover plate black matt - Busch-art linear  | LEW/A.1.70.11-45M  | 1 | piece |
| 2CKA006199A0420 | Cover plate black matt - Busch-art linear  | LEW/A.2.70.11-45M  | 1 | piece |
| 2CKA006199A0421 | Cover plate black matt - Busch-art linear  | LEW/A.3.70.11-45M  | 1 | piece |
| 2CKA006199A0422 | Cover plate black matt - Busch-art linear  | LEW/A.4.70.11-45M  | 1 | piece |
| 2CKA006199A0423 | Cover plate Symbol "light" LFB/A.1.70.11-45M black matt - Busch-art linear                   | LFB/A.1.70.11-45M  | 1 | piece |
| 2CKA006199A0424 | Cover plate Symbol "venetian blind" black matt - Busch-art linear                            | LFJ/A.1.70.11-45M  | 1 | piece |
| 2CKA006199A0425 | Cover plate Symbol "scene" black matt - Busch-art linear                                     | LFS/A.1.70.11-45M  | 1 | piece |
| 2CKA006199A0426 | Cover plate Symbol "dimming" black matt - Busch-art linear                                   | LFDW/A.1.70.11-45M | 1 | piece |
| 2CKA006199A0427 | Cover plate Symbol "venetian blind" black matt - Busch-art linear                            | LFJW/A.1.70.11-45M | 1 | piece |
| 2CKA006199A0428 | Cover plate Symbol "arrows" black matt - Busch-art linear                                    | LEAW/A.1.70.11-45M | 1 | piece |

|                 |   |                    |   |       |
|-----------------|---|--------------------|---|-------|
| 2CKA006199A0429 | Cover plate Symbol "light" LFBT/A.2.70.11-45M black matt - Busch-art linear           |                    | 1 | piece |
| 2CKA006199A0430 | Cover plate Symbol "venetian blind" black matt - Busch-art linear                     | LFJT/A.2.70.11-45M | 1 | piece |
| 2CKA006199A0431 | Cover plate Symbol "scene" black matt - Busch-art linear                              | LFST/A.2.70.11-45M | 1 | piece |
| 2CKA006199A0432 | Cover plate Symbol "arrows/venetian blind" and "dimmer" black matt - Busch-art linear | LFDW/A.2.70.11-45M | 1 | piece |
| 2CKA006199A0433 | Cover plate Symbol "arrows" black matt - Busch-art linear                             | LFAW/A.2.70.11-45M | 1 | piece |
| 2CKA006199A0434 | Cover plate Symbols "music control" black matt - Busch-art linear                     | LFMW/A.4.70.11-45M | 1 | piece |
| 2CKA006199A0435 | Cover plate studio white - Trevion  | LFW/A.1.70.1-44G   | 1 | piece |
| 2CKA006199A0436 | Cover plate studio white - Trevion  | LFW/A.2.70.1-44G   | 1 | piece |
| 2CKA006199A0437 | Cover plate studio white - Trevion  | LFW/A.3.70.1-44G   | 1 | piece |
| 2CKA006199A0438 | Cover plate studio white - Trevion  | LFW/A.4.70.1-44G   | 1 | piece |
| 2CKA006199A0439 | Cover plate Symbol "light" LFB/A.1.70.1-44G studio white - Trevion                    |                    | 1 | piece |
| 2CKA006199A0440 | Cover plate Symbol "venetian blind" studio white - Trevion                            | LFJ/A.1.70.1-44G   | 1 | piece |
| 2CKA006199A0441 | Cover plate Symbol "scene" studio white - Trevion                                     | LFS/A.1.70.1-44G   | 1 | piece |
| 2CKA006199A0442 | Cover plate Symbol "dimming" studio white - Trevion                                   | LFDW/A.1.70.1-44G  | 1 | piece |
| 2CKA006199A0443 | Cover plate Symbol "venetian blind" studio white - Trevion                            | LFJW/A.1.70.1-44G  | 1 | piece |
| 2CKA006199A0444 | Cover plate Symbol "arrows" studio white - Trevion                                    | LFAW/A.1.70.1-44G  | 1 | piece |
| 2CKA006199A0445 | Cover plate Symbol "light" LFBT/A.2.70.1-44G studio white - Trevion                   |                    | 1 | piece |
| 2CKA006199A0446 | Cover plate Symbol "venetian blind" studio white - Trevion                            | LFJT/A.2.70.1-44G  | 1 | piece |
| 2CKA006199A0447 | Cover plate Symbol "scene" studio white - Trevion                                     | LFST/A.2.70.1-44G  | 1 | piece |
| 2CKA006199A0448 | Cover plate Symbol "arrows/venetian blind" and "dimmer" studio white - Trevion        | LFDW/A.2.70.1-44G  | 1 | piece |

|                 |   |                   |   |       |
|-----------------|---|-------------------|---|-------|
| 2CKA006199A0449 | Cover plate Symbol "arrows" studio white - Trevion                                  | LFAW/A.2.70.1-44G | 1 | piece |
| 2CKA006199A0450 | Cover plate Symbols "music control" studio white - Trevion                          | LFMW/A.4.70.1-44G | 1 | piece |
| 2CKA006199A0451 | Cover plate studio white matt - Trevion   | LFW/A.1.70.1-44M  | 1 | piece |
| 2CKA006199A0452 | Cover plate studio white matt - Trevion   | LFW/A.2.70.1-44M  | 1 | piece |
| 2CKA006199A0453 | Cover plate studio white matt - Trevion   | LFW/A.3.70.1-44M  | 1 | piece |
| 2CKA006199A0454 | Cover plate studio white matt - Trevion   | LFW/A.4.70.1-44M  | 1 | piece |
| 2CKA006199A0455 | Cover plate Symbol "light" studio white matt - Trevion                              | LFB/A.1.70.1-44M  | 1 | piece |
| 2CKA006199A0456 | Cover plate Symbol "venetian blind" studio white matt - Trevion                     | LFJ/A.1.70.1-44M  | 1 | piece |
| 2CKA006199A0457 | Cover plate Symbol "scene" studio white matt - Trevion                              | LFS/A.1.70.1-44M  | 1 | piece |
| 2CKA006199A0458 | Cover plate Symbol "dimming" studio white matt - Trevion                            | LFDW/A.1.70.1-44M | 1 | piece |
| 2CKA006199A0459 | Cover plate Symbol "venetian blind" studio white matt - Trevion                     | LFJW/A.1.70.1-44M | 1 | piece |
| 2CKA006199A0460 | Cover plate Symbol "arrows" studio white matt - Trevion                             | LFAW/A.1.70.1-44M | 1 | piece |
| 2CKA006199A0461 | Cover plate Symbol "light" studio white matt - Trevion                              | LFBT/A.2.70.1-44M | 1 | piece |
| 2CKA006199A0462 | Cover plate Symbol "venetian blind" studio white matt - Trevion                     | LFJT/A.2.70.1-44M | 1 | piece |
| 2CKA006199A0463 | Cover plate Symbol "scene" studio white matt - Trevion                              | LFST/A.2.70.1-44M | 1 | piece |
| 2CKA006199A0464 | Cover plate Symbol "arrows/venetian blind" and "dimmer" studio white matt - Trevion | LFDW/A.2.70.1-44M | 1 | piece |
| 2CKA006199A0465 | Cover plate Symbol "arrows" studio white matt - Trevion                             | LFAW/A.2.70.1-44M | 1 | piece |
| 2CKA006199A0466 | Cover plate Symbols "music control" studio white matt - Trevion                     | LFMW/A.4.70.1-44M | 1 | piece |
| 2CKA006199A0483 | Cover plate black matt - Trevion  | LFW/A.1.70.1-45M  | 1 | piece |
| 2CKA006199A0484 | Cover plate black matt - Trevion  | LFW/A.2.70.1-45M  | 1 | piece |
| 2CKA006199A0485 | Cover plate black matt - Trevion  | LFW/A.3.70.1-45M  | 1 | piece |

|                 |  |                   |   |       |
|-----------------|--|-------------------|---|-------|
| 2CKA006199A0486 | Cover plate black matt - Trevion   | LFW/A.4.70.1-45M  | 1 | piece |
| 2CKA006199A0487 | Cover plate Symbol "light" black matt - Trevion                              | LFB/A.1.70.1-45M  | 1 | piece |
| 2CKA006199A0488 | Cover plate Symbol "venetian blind" black matt - Trevion                     | LFJ/A.1.70.1-45M  | 1 | piece |
| 2CKA006199A0489 | Cover plate Symbol "scene" black matt - Trevion                              | LFS/A.1.70.1-45M  | 1 | piece |
| 2CKA006199A0490 | Cover plate Symbol "dimming" black matt - Trevion                            | LFDW/A.1.70.1-45M | 1 | piece |
| 2CKA006199A0491 | Cover plate Symbol "venetian blind" black matt - Trevion                     | LFJW/A.1.70.1-45M | 1 | piece |
| 2CKA006199A0492 | Cover plate Symbol "arrows" black matt - Trevion                             | LFAW/A.1.70.1-45M | 1 | piece |
| 2CKA006199A0493 | Cover plate Symbol "light" black matt - Trevion                              | LFBT/A.2.70.1-45M | 1 | piece |
| 2CKA006199A0494 | Cover plate Symbol "venetian blind" black matt - Trevion                     | LFJT/A.2.70.1-45M | 1 | piece |
| 2CKA006199A0495 | Cover plate Symbol "scene" black matt - Trevion                              | LFST/A.2.70.1-45M | 1 | piece |
| 2CKA006199A0496 | Cover plate Symbol "arrows/venetian blind" and "dimmer" black matt - Trevion | LFDW/A.2.70.1-45M | 1 | piece |
| 2CKA006199A0497 | Cover plate Symbol "arrows" black matt - Trevion                             | LFAW/A.2.70.1-45M | 1 | piece |
| 2CKA006199A0498 | Cover plate Symbols "music control" black matt - Trevion                     | LFMW/A.4.70.1-45M | 1 | piece |

## Categories

Products > Low Voltage Products and Systems > Building and Home Automation Solutions > free@home > User Operation > Frames

Products > Low Voltage Products and Systems > Building and Home Automation Solutions > KNX > User Operation > Frames

Products > Low Voltage Products and Systems > Wiring Accessories - Light Switch Ranges > Frames

