



PRODUCT-DETAILS

1743-44G-500

Cover plate TV / Radio / SAT 3 gang studio white - Busch-art linear



General Information

Extended Product Type:	1743-44G-500
Product ID:	2CKA001724A4436
EAN:	4011395317020
Catalog Description:	Cover plate TV / Radio / SAT 3 gang studio white - Busch-art linear
Long Description:	With 2 connectors Acc. to German Standard DIN 45330. Radio/TV/SAT. With M3 fixing screw.
Display Name:	1743-44G-500

Installation

Instructions and Manuals:	No document needed
Mounting Type:	Flush Mounted
Type of Fastening:	Mounting with Screw
Modular Components Included:	Cover Plate

Environmental

Degree of Protection: IP20

Technical

Data Sheet, Technical Information: No document needed

Application: TV / Radio / SAT

Function: knock out third opening

Type of Indicator: Without indication field

Outlet Orientation: Straight

Design

Design Range: Busch-art linear

Design Range Variant: Busch-art linear
Busch-art linear - with Decor Ring
Busch-art linear - pur

Surface Finishing: Untreated
Glossy

Material: Thermoplastic

RAL Number: Similar to RAL 9016

Color: studio white

Number of Gangs: 1-gang

Dimensions

Product Net Width: 69.5 mm

Product Net Height: 69.5 mm

Product Net Depth / Length: 24.77 mm

Product Net Weight: 11.6 g

Material Compliance

RoHS Declaration: 2CKA200000E8117

RoHS Information: Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019

REACH Declaration: 2CKA309999E9999

REACH Information: False - does not contain substances > 0.1 mass percentage

REACH Date: 20260216

Conflict Minerals Reporting Template (CMRT): 9AKK108468A3363

WEEE Category: Product Not in WEEE Scope

Certificates and Declarations

Declaration of Conformity - CE: No declaration needed

EU Data Act Applicability and Compliance: Not Applicable

External Classifications and Standards

ETIM 9: EC000018 - Insert/cover for communication technology

ETIM 10: EC000018 - Insert/cover for communication technology

eClass: V11.0 : 27144049

Accessories

Identifier	Description	Type	Qty	Unit Of Measure
2CKA000230A0250	Antenna socket insert TV / SAT End socket Straight version	0230-101	1	piece
2CKA000230A0380	Antenna socket insert TV / SAT End socket	0230-101-507	1	piece
2CKA000230A1554	Antenna socket insert TV / SAT End socket Straight version	0230-102	1	piece
2CKA000230A1556	Antenna socket insert TV / SAT End socket Straight version	0230-102-500	1	piece
2CKA000230A0268	Antenna socket insert TV / SAT Loop-through socket Straight version	0231-101	1	piece
2CKA000230A1555	Antenna socket insert TV / SAT Loop-through socket Straight version	0231-102	1	piece
2CKA000230A1557	Antenna socket insert TV / SAT Loop-through socket Straight version	0231-102-500	1	piece
2CKA000230A0384	Antenna socket insert TV / Radio / SAT End socket Straight version	0232-101	1	piece
2CKA001754A4837	Cover frame 1-gang studio white - Busch-art linear	1721-44G	1	piece
2CKA001754A4841	Cover frame 1-gang studio white - Busch-art linear	1721-44G-500	1	piece
2CLA897100A3958	Cover frame 1-gang glass blue - Busch-art linear	1721-4028	1	piece
2CKA001754A4932	Cover frame 1-gang glass blue - Busch-art linear	1721-4028-101	1	piece
2CKA001754A4877	Cover frame 1-gang glass black - Busch-art linear	1721-4025	1	piece
2CKA001754A4882	Cover frame 1-gang glass black / gold - Busch-art linear	1721-4013	1	piece

2CKA001754A4838	Cover frame 1-gang studio white matt - Busch-art linear	1721-44M	1	piece
2CKA001754A4842	Cover frame 1-gang studio white matt - Busch-art linear	1721-44M-500	1	piece
2CKA001754A4897	Cover frame 1-gang paper black - Busch-art linear	1721-4045	1	piece
2CKA001754A4840	Cover frame 1-gang black matt - Busch-art linear	1721-45M	1	piece
2CKA001754A4844	Cover frame 1-gang black matt - Busch-art linear	1721-45M-500	1	piece
2CKA001754A4887	Cover frame 1-gang wood oak - Busch-art linear	1721-4083	1	piece
2CKA001754A4892	Cover frame 1-gang wood walnut - Busch-art linear	1721-4086	1	piece
2CKA001754A4902	Cover frame with decor ring 1-gang studio white matt / rose gold - Busch-art linear	1721-441M	1	piece
2CKA001754A4905	Cover frame with decor ring 1-gang studio white matt / rose gold - Busch-art linear	1721-441M-500	1	piece
2CLA897100A1758	Cover frame 1-gang aluminium silver - Busch-art linear	1721-4073	1	piece
2CKA001754A4904	Cover frame with decor ring 1-gang black matt / chrome - Busch-art linear	1721-456M	1	piece
2CKA001754A4907	Cover frame with decor ring 1-gang black matt / chrome - Busch-art linear	1721-456M-500	1	piece
2CLA897100A2958	Cover frame 1-gang slate terra rosso - Busch-art linear	1721-4097	1	piece
2CKA001754A4903	Cover frame with decor ring 1-gang black matt / gold - Busch-art linear	1721-453M	1	piece
2CKA001754A4906	Cover frame with decor ring 1-gang black matt / gold - Busch-art linear	1721-453M-500	1	piece
2CKA001754A4845	Cover frame 2-gang studio white - Busch-art linear	1722-44G	1	piece
2CKA001754A4849	Cover frame 2-gang studio white - Busch-art linear	1722-44G-500	1	piece
2CLA897200A3958	Cover frame 2-gang glass blue - Busch-art linear	1722-4028	1	piece
2CKA001754A4933	Cover frame 2-gang glass blue - Busch-art linear	1722-4028-101	1	piece
2CKA001754A4878	Cover frame 2-gang glass black - Busch-art linear	1722-4025	1	piece
2CKA001754A4883	Cover frame 2-gang glass black / gold - Busch-art linear	1722-4013	1	piece

2CKA001754A4846	Cover frame 2-gang studio white matt - Busch-art linear	1722-44M	1	piece
2CKA001754A4850	Cover frame 2-gang studio white matt - Busch-art linear	1722-44M-500	1	piece
2CKA001754A4898	Cover frame 2-gang paper black - Busch-art linear	1722-4045	1	piece
2CKA001754A4848	Cover frame 2-gang black matt - Busch-art linear	1722-45M	1	piece
2CKA001754A4852	Cover frame 2-gang black matt - Busch-art linear	1722-45M-500	1	piece
2CKA001754A4888	Cover frame 2-gang wood oak - Busch-art linear	1722-4083	1	piece
2CKA001754A4893	Cover frame 2-gang wood walnut - Busch-art linear	1722-4086	1	piece
2CKA001754A4908	Cover frame with decor ring 2-gang studio white matt / rose gold - Busch-art linear	1722-441M	1	piece
2CKA001754A4911	Cover frame with decor ring 2-gang studio white matt / rose gold - Busch-art linear	1722-441M-500	1	piece
2CLA897200A1758	Cover frame 2-gang aluminium silver - Busch-art linear	1722-4073	1	piece
2CKA001754A4910	Cover frame with decor ring 2-gang black matt / chrome - Busch-art linear	1722-456M	1	piece
2CKA001754A4913	Cover frame with decor ring 2-gang black matt / chrome - Busch-art linear	1722-456M-500	1	piece
2CLA897200A2958	Cover frame 2-gang slate terra rosso - Busch-art linear	1722-4097	1	piece
2CKA001754A4909	Cover frame with decor ring 2-gang black matt / gold - Busch-art linear	1722-453M	1	piece
2CKA001754A4912	Cover frame with decor ring 2-gang black matt / gold - Busch-art linear	1722-453M-500	1	piece
2CKA001754A4853	Cover frame 3-gang studio white - Busch-art linear	1723-44G	1	piece
2CKA001754A4857	Cover frame 3-gang studio white - Busch-art linear	1723-44G-500	1	piece
2CLA897300A3958	Cover frame with decor ring 3-gang glass blue - Busch-art linear	1723-4028	1	piece
2CKA001754A4934	Cover frame with decor ring 3-gang glass blue - Busch-art linear	1723-4028-101	1	piece
2CKA001754A4879	Cover frame 3-gang glass black - Busch-art linear	1723-4025	1	piece

2CKA001754A4884	Cover frame 3-gang glass 1723-4013 black / gold - Busch-art linear		1	piece
2CKA001754A4854	Cover frame 3-gang 1723-44M studio white matt - Busch -art linear		1	piece
2CKA001754A4858	Cover frame 3-gang 1723-44M-500 studio white matt - Busch -art linear		1	piece
2CKA001754A4899	Cover frame 3-gang paper1723-4045 black - Busch-art linear		1	piece
2CKA001754A4856	Cover frame 3-gang black 1723-45M matt - Busch-art linear		1	piece
2CKA001754A4860	Cover frame 3-gang black 1723-45M-500 matt - Busch-art linear		1	piece
2CKA001754A4889	Cover frame 3-gang wood 1723-4083 oak - Busch-art linear		1	piece
2CKA001754A4894	Cover frame 3-gang wood 1723-4086 walnut - Busch-art linear		1	piece
2CKA001754A4914	Cover frame with decor 1723-441M ring 3-gang studio white matt / rose gold - Busch- art linear		1	piece
2CKA001754A4917	Cover frame with decor 1723-441M-500 ring 3-gang studio white matt / rose gold - Busch- art linear		1	piece
2CLA897300A1758	Cover frame 3-gang 1723-4073 aluminium silver - Busch- art linear		1	piece
2CKA001754A4916	Cover frame with decor 1723-456M ring 3-gang black matt / chrome - Busch-art linear		1	piece
2CKA001754A4919	Cover frame with decor 1723-456M-500 ring 3-gang black matt / chrome - Busch-art linear		1	piece
2CLA897300A2958	Cover frame 3-gang slate 1723-4097 terra rosso - Busch-art linear		1	piece
2CKA001754A4915	Cover frame with decor 1723-453M ring 3-gang black matt / gold - Busch-art linear		1	piece
2CKA001754A4918	Cover frame with decor 1723-453M-500 ring 3-gang black matt / gold - Busch-art linear		1	piece
2CKA001754A4861	Cover frame 4-gang 1724-44G studio white - Busch-art linear		1	piece
2CKA001754A4865	Cover frame 4-gang 1724-44G-500 studio white - Busch-art linear		1	piece
2CLA897400A3958	Cover frame 4-gang glass 1724-4028 blue - Busch-art linear		1	piece
2CKA001754A4935	Cover frame 4-gang glass 1724-4028-101 blue - Busch-art linear		1	piece
2CKA001754A4880	Cover frame 4-gang glass 1724-4025 black - Busch-art linear		1	piece

2CKA001754A4885	Cover frame 4-gang glass 1724-4013 black / gold - Busch-art linear		1	piece
2CKA001754A4862	Cover frame 4-gang 1724-44M studio white matt - Busch -art linear		1	piece
2CKA001754A4866	Cover frame 4-gang 1724-44M-500 studio white matt - Busch -art linear		1	piece
2CKA001754A4900	Cover frame 4-gang paper1724-4045 black - Busch-art linear		1	piece
2CKA001754A4864	Cover frame 4-gang black 1724-45M matt - Busch-art linear		1	piece
2CKA001754A4868	Cover frame 4-gang black 1724-45M-500 matt - Busch-art linear		1	piece
2CKA001754A4890	Cover frame 4-gang wood1724-4083 oak - Busch-art linear		1	piece
2CKA001754A4895	Cover frame 4-gang wood1724-4086 walnut - Busch-art linear		1	piece
2CKA001754A4920	Cover frame with decor 1724-441M ring 4-gang studio white matt / rose gold - Busch- art linear		1	piece
2CKA001754A4923	Cover frame with decor 1724-441M-500 ring 4-gang studio white matt / rose gold - Busch- art linear		1	piece
2CLA897400A1758	Cover frame 4-gang 1724-4073 aluminium silver - Busch- art linear		1	piece
2CKA001754A4922	Cover frame with decor 1724-456M ring 4-gang black matt / chrome - Busch-art linear		1	piece
2CKA001754A4925	Cover frame with decor 1724-456M-500 ring 4-gang black matt / chrome - Busch-art linear		1	piece
2CLA897400A2958	Cover frame 4-gang slate 1724-4097 terra rosso - Busch-art linear		1	piece
2CKA001754A4921	Cover frame with decor 1724-453M ring 4-gang black matt / gold - Busch-art linear		1	piece
2CKA001754A4924	Cover frame with decor 1724-453M-500 ring 4-gang black matt / gold - Busch-art linear		1	piece
2CKA001754A4869	Cover frame 5-gang 1725-44G studio white - Busch-art linear		1	piece
2CKA001754A4873	Cover frame 5-gang 1725-44G-500 studio white - Busch-art linear		1	piece
2CLA897500A3958	Cover frame 5-gang glass 1725-4028 blue - Busch-art linear		1	piece
2CKA001754A4936	Cover frame 5-gang glass 1725-4028-101 blue - Busch-art linear		1	piece
2CKA001754A4881	Cover frame 5-gang glass 1725-4025 black - Busch-art linear		1	piece

2CKA001754A4886	Cover frame 5-gang glass 1725-4013 black / gold - Busch-art linear		1	piece
2CKA001754A4870	Cover frame 5-gang 1725-44M studio white matt - Busch -art linear		1	piece
2CKA001754A4874	Cover frame 5-gang 1725-44M-500 studio white matt - Busch -art linear		1	piece
2CKA001754A4901	Cover frame 5-gang paper1725-4045 black - Busch-art linear		1	piece
2CKA001754A4872	Cover frame 5-gang black 1725-45M matt - Busch-art linear		1	piece
2CKA001754A4876	Cover frame 5-gang black 1725-45M-500 matt - Busch-art linear		1	piece
2CKA001754A4891	Cover frame 5-gang wood 1725-4083 oak - Busch-art linear		1	piece
2CKA001754A4896	Cover frame 5-gang wood 1725-4086 walnut - Busch-art linear		1	piece
2CKA001754A4926	Cover frame with decor 1725-441M ring 5-gang studio white matt / rose gold - Busch- art linear		1	piece
2CKA001754A4929	Cover frame with decor 1725-441M-500 ring 5-gang studio white matt / rose gold - Busch- art linear		1	piece
2CLA897500A1758	Cover frame 5-gang 1725-4073 aluminium silver - Busch- art linear		1	piece
2CKA001754A4928	Cover frame with decor 1725-456M ring 5-gang black matt / chrome - Busch-art linear		1	piece
2CKA001754A4931	Cover frame with decor 1725-456M-500 ring 5-gang black matt / chrome - Busch-art linear		1	piece
2CLA897500A2958	Cover frame 5-gang slate 1725-4097 terra rosso - Busch-art linear		1	piece
2CKA001754A4927	Cover frame with decor 1725-453M ring 5-gang black matt / gold - Busch-art linear		1	piece
2CKA001754A4930	Cover frame with decor 1725-453M-500 ring 5-gang black matt / gold - Busch-art linear		1	piece

Categories

Products > Low Voltage Products and Systems > Wiring Accessories - Light Switch Ranges > Cover Plates and Control Elements > Data / Telecommunication / Antenna

