




---

**PRODUCT-DETAILS**

# 1786-44M-500

## Rocker for Switch/push button, Single rocker studio white matt - Busch-art linear



---

**General Information**

<b>Extended Product Type:</b>	1786-44M-500
<b>Product ID:</b>	2CKA001751A3338
<b>EAN:</b>	4011395320013
<b>Catalog Description:</b>	Rocker for Switch/push button, Single rocker studio white matt - Busch-art linear
<b>Long Description:</b>	For flush-mounted switch 1g1w, 1g2w, intermediate, push switch.
<b>Display Name:</b>	1786-44M-500

---

**Installation**

<b>Instructions and Manuals:</b>	No document needed
<b>Mounting Type:</b>	Flush Mounted
<b>Modular Components Included:</b>	Rocker / Push Button

---

**Environmental**

Degree of Protection: IP20

## Technical

Data Sheet, Technical Information: No document needed

Application: Switch/push button

## Design

Design Range: Busch-art linear

Design Range Variant: Busch-art linear  
Busch-art linear - with Decor Ring  
Busch-art linear - pur

Surface Finishing: Lacquered  
Matt

Material: Thermoplastic

RAL Number: Similar to RAL 9016

Color: studio white matt

## Dimensions

Product Net Width: 69.5 mm

Product Net Height: 69.5 mm

Product Net Depth / Length: 23.29 mm

Product Net Weight: 22.4 g

## Material Compliance

RoHS Declaration: 2CKA200000E7948

RoHS Information: Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019

REACH Declaration: 2CKA309999E9999

REACH Information: False - does not contain substances > 0.1 mass percentage

REACH Date: 20260216

Conflict Minerals Reporting Template (CMRT): 9AKK108468A3363

WEEE Category: Product Not in WEEE Scope

## Certificates and Declarations

Declaration of Conformity - CE: No declaration needed

EU Data Act Applicability and Compliance: Not Applicable

## External Classifications and Standards

<b>ETIM 9:</b>	EC000011 - Control element/cover plate for domestic switching devices
<b>ETIM 10:</b>	EC000011 - Control element/cover plate for domestic switching devices
<b>eClass:</b>	V11.0 : 27144002

## Accessories

Identifier	Description	Type	Qty	Unit Of Measure
2CKA001012A2059	Flush Mounted Inserts Off2000/1 US-500 switch 1-pole for 1 rocker, 10 A		1	piece
2CKA001012A2131	Flush Mounted Inserts Off2000/1 US-507 switch 1-pole for 1 rocker, 10 A		1	piece
2CKA001012A1069	Switch insert Two-way switch for 1 rocker, 10 A	2000/6 US	1	piece
2CKA001012A2231	Switch insert Two-way switch for 1 rocker, 16 A	2400/6 US	1	piece
2CKA001012A2232	Flush Mounted Inserts Single push button Two-way switch for 1 rocker, 16 A	2400/6 US-500	1	piece
2CKA001012A2198	Switch insert Single push button Two-way switch for 1 rocker, 10 A	2000/6 US-500	1	piece
2CKA001012A1143	Switch insert Single push button Two-way switch for 1 rocker, 10 A	2000/6 US-506	1	piece
2CKA001012A2110	Flush Mounted Inserts Single push button Two-way switch for 1 rocker, 10 A	2000/6 US-507	1	piece
2CKA001012A1598	Insert Single push button Two-way switch for 1 rocker, 10 A	2000/6 USR-503	1	piece
2CKA001012A1093	Switch insert Intermediate switch for 1 rocker, 10 A	2000/7 US	1	piece
2CKA001012A2199	Flush Mounted Inserts Single push button Intermediate switch for 1 rocker, 10 A	2000/7 US-500	1	piece
2CKA001012A1168	Flush Mounted Inserts Single push button Intermediate switch for 1 rocker, 10 A	2000/7 US-506	1	piece
2CKA001012A2130	Flush Mounted Inserts Single push button Intermediate switch for 1 rocker, 10 A	2000/7 US-507	1	piece
2CKA001012A2235	Switch insert Intermediate switch for 1 rocker, 16 A	2400/7 US	1	piece

2CKA001012A2236	Flush Mounted Inserts Single push button Intermediate switch for 1 rocker, 16 A	2400/7 US-500	1	piece
2CKA001413A0475	Push switch insert Single push button 1-pole push switch for 1 rocker, 1 NO 10 A	2020 US	1	piece
2CKA001413A0574	Flush Mounted Inserts Single push button with N -terminal 10 A	2020 US-500	1	piece
2CKA001413A1078	Flush Mounted Inserts Single push button for 1 rocker, with N-terminal 10 A	2020 US-507	1	piece
2CKA001413A0483	Push switch insert Single push button 1-pole push switch for 1 rocker, 1 NO 10 A	2020 US-201	1	piece
2CKA001413A0517	Push switch insert Single push button Two-way push switch for 1 rocker, 1 NO 1 NC 1 CO 10 A	2020 US-206	1	piece
2CKA001413A1104	Push switch insert Single push button Two-way push switch for 1 rocker, 1 NO 1 NC 1 CO with N- terminal 10 A	2020 US-206-500	1	piece
2CKA001022A0656	Rocker control switch Off switch 2-pole for 1 rocker, Neon lamp/Orange 10 A	2000/2 UK	1	piece
2CKA001012A2034	Switch insert Off switch 2 -pole for 1 rocker, 10 A	2000/2 US	1	piece
2CKA001012A2196	Flush Mounted Inserts Single push button 2-pole switch for 1 rocker, 10 A	2000/2 US-500	1	piece
2CKA001012A2042	Switch insert Off switch 2 -pole for 1 rocker, 16 A	2000/2 US-101	1	piece
2CKA001012A2193	Flush Mounted Inserts Single push button 2-pole switch for 1 rocker, 16 A	2000/2 US-101-500	1	piece
2CKA001012A0954	Switch insert Two-way switch 2-pole for 1 rocker, 10 A	2000/6/2 US	1	piece
2CKA001011A0816	Switch insert 3-pole switch for 1 rocker, 16 A	2000/3 US	1	piece
2CKA006133A0224	Push Button Coupler with LED Control light 24 V KNX (TP)	6108/06-AP	1	piece
2CKA006133A0225	Ocean with LED Control light 24 V KNX (TP)	6108/06-AP-500	1	piece
2CKA001754A4842	Cover frame 1-gang studio white matt - Busch -art linear	1721-44M-500	1	piece
2CKA001754A4840	Cover frame 1-gang black matt - Busch-art linear	1721-45M	1	piece
2CKA001754A4844	Cover frame 1-gang black matt - Busch-art linear	1721-45M-500	1	piece

2CKA001754A4902	Cover frame with decor ring 1-gang studio white matt / rose gold - Busch-art linear	1721-441M	1	piece
2CKA001754A4905	Cover frame with decor ring 1-gang studio white matt / rose gold - Busch-art linear	1721-441M-500	1	piece
2CKA001754A4904	Cover frame with decor ring 1-gang black matt / chrome - Busch-art linear	1721-456M	1	piece
2CKA001754A4907	Cover frame with decor ring 1-gang black matt / chrome - Busch-art linear	1721-456M-500	1	piece
2CKA001754A4903	Cover frame with decor ring 1-gang black matt / gold - Busch-art linear	1721-453M	1	piece
2CKA001754A4906	Cover frame with decor ring 1-gang black matt / gold - Busch-art linear	1721-453M-500	1	piece
2CLA897100A3958	Cover frame 1-gang glass blue - Busch-art linear	1721-4028	1	piece
2CKA001754A4877	Cover frame 1-gang glass black - Busch-art linear	1721-4025	1	piece
2CKA001754A4882	Cover frame 1-gang glass black / gold - Busch-art linear	1721-4013	1	piece
2CKA001754A4897	Cover frame 1-gang paper black - Busch-art linear	1721-4045	1	piece
2CKA001754A4887	Cover frame 1-gang wood oak - Busch-art linear	1721-4083	1	piece
2CKA001754A4892	Cover frame 1-gang wood walnut - Busch-art linear	1721-4086	1	piece
2CLA897100A1758	Cover frame 1-gang aluminium silver - Busch-art linear	1721-4073	1	piece
2CLA897100A2958	Cover frame 1-gang slate terra rosso - Busch-art linear	1721-4097	1	piece
2CKA001754A4845	Cover frame 2-gang studio white - Busch-art linear	1722-44G	1	piece
2CKA001754A4849	Cover frame 2-gang studio white - Busch-art linear	1722-44G-500	1	piece
2CKA001754A4846	Cover frame 2-gang studio white matt - Busch-art linear	1722-44M	1	piece
2CKA001754A4850	Cover frame 2-gang studio white matt - Busch-art linear	1722-44M-500	1	piece
2CKA001754A4848	Cover frame 2-gang black matt - Busch-art linear	1722-45M	1	piece
2CKA001754A4852	Cover frame 2-gang black matt - Busch-art linear	1722-45M-500	1	piece

2CKA001754A4908	Cover frame with decor ring 2-gang studio white matt / rose gold - Busch-art linear	1722-441M	1	piece
2CKA001754A4911	Cover frame with decor ring 2-gang studio white matt / rose gold - Busch-art linear	1722-441M-500	1	piece
2CKA001754A4910	Cover frame with decor ring 2-gang black matt / chrome - Busch-art linear	1722-456M	1	piece
2CKA001754A4913	Cover frame with decor ring 2-gang black matt / chrome - Busch-art linear	1722-456M-500	1	piece
2CKA001754A4909	Cover frame with decor ring 2-gang black matt / gold - Busch-art linear	1722-453M	1	piece
2CKA001754A4912	Cover frame with decor ring 2-gang black matt / gold - Busch-art linear	1722-453M-500	1	piece
2CLA897200A3958	Cover frame 2-gang glass blue - Busch-art linear	1722-4028	1	piece
2CKA001754A4878	Cover frame 2-gang glass black - Busch-art linear	1722-4025	1	piece
2CKA001754A4883	Cover frame 2-gang glass black / gold - Busch-art linear	1722-4013	1	piece
2CKA001754A4898	Cover frame 2-gang paper black - Busch-art linear	1722-4045	1	piece
2CKA001754A4888	Cover frame 2-gang wood oak - Busch-art linear	1722-4083	1	piece
2CKA001754A4893	Cover frame 2-gang wood walnut - Busch-art linear	1722-4086	1	piece
2CLA897200A1758	Cover frame 2-gang aluminium silver - Busch-art linear	1722-4073	1	piece
2CLA897200A2958	Cover frame 2-gang slate terra rosso - Busch-art linear	1722-4097	1	piece
2CKA001754A4853	Cover frame 3-gang studio white - Busch-art linear	1723-44G	1	piece
2CKA001754A4857	Cover frame 3-gang studio white - Busch-art linear	1723-44G-500	1	piece
2CKA001754A4854	Cover frame 3-gang studio white matt - Busch-art linear	1723-44M	1	piece
2CKA001754A4858	Cover frame 3-gang studio white matt - Busch-art linear	1723-44M-500	1	piece
2CKA001754A4856	Cover frame 3-gang black matt - Busch-art linear	1723-45M	1	piece
2CKA001754A4860	Cover frame 3-gang black matt - Busch-art linear	1723-45M-500	1	piece

2CKA001754A4914	Cover frame with decor ring 3-gang studio white matt / rose gold - Busch-art linear	1723-441M	1	piece
2CKA001754A4917	Cover frame with decor ring 3-gang studio white matt / rose gold - Busch-art linear	1723-441M-500	1	piece
2CKA001754A4916	Cover frame with decor ring 3-gang black matt / chrome - Busch-art linear	1723-456M	1	piece
2CKA001754A4919	Cover frame with decor ring 3-gang black matt / chrome - Busch-art linear	1723-456M-500	1	piece
2CKA001754A4915	Cover frame with decor ring 3-gang black matt / gold - Busch-art linear	1723-453M	1	piece
2CKA001754A4918	Cover frame with decor ring 3-gang black matt / gold - Busch-art linear	1723-453M-500	1	piece
2CLA897300A3958	Cover frame with decor ring 3-gang glass blue - Busch-art linear	1723-4028	1	piece
2CKA001754A4879	Cover frame 3-gang glass black - Busch-art linear	1723-4025	1	piece
2CKA001754A4884	Cover frame 3-gang glass black / gold - Busch-art linear	1723-4013	1	piece
2CKA001754A4899	Cover frame 3-gang paper black - Busch-art linear	1723-4045	1	piece
2CKA001754A4889	Cover frame 3-gang wood oak - Busch-art linear	1723-4083	1	piece
2CKA001754A4894	Cover frame 3-gang wood walnut - Busch-art linear	1723-4086	1	piece
2CLA897300A1758	Cover frame 3-gang aluminium silver - Busch-art linear	1723-4073	1	piece
2CLA897300A2958	Cover frame 3-gang slate terra rosso - Busch-art linear	1723-4097	1	piece
2CKA001754A4861	Cover frame 4-gang studio white - Busch-art linear	1724-44G	1	piece
2CKA001754A4865	Cover frame 4-gang studio white - Busch-art linear	1724-44G-500	1	piece
2CKA001754A4862	Cover frame 4-gang studio white matt - Busch-art linear	1724-44M	1	piece
2CKA001754A4866	Cover frame 4-gang studio white matt - Busch-art linear	1724-44M-500	1	piece
2CKA001754A4864	Cover frame 4-gang black matt - Busch-art linear	1724-45M	1	piece
2CKA001754A4868	Cover frame 4-gang black matt - Busch-art linear	1724-45M-500	1	piece

2CKA001754A4920	Cover frame with decor ring 4-gang studio white matt / rose gold - Busch-art linear	1724-441M	1	piece
2CKA001754A4923	Cover frame with decor ring 4-gang studio white matt / rose gold - Busch-art linear	1724-441M-500	1	piece
2CKA001754A4922	Cover frame with decor ring 4-gang black matt / chrome - Busch-art linear	1724-456M	1	piece
2CKA001754A4925	Cover frame with decor ring 4-gang black matt / chrome - Busch-art linear	1724-456M-500	1	piece
2CKA001754A4921	Cover frame with decor ring 4-gang black matt / gold - Busch-art linear	1724-453M	1	piece
2CKA001754A4924	Cover frame with decor ring 4-gang black matt / gold - Busch-art linear	1724-453M-500	1	piece
2CLA897400A3958	Cover frame 4-gang glass blue - Busch-art linear	1724-4028	1	piece
2CKA001754A4880	Cover frame 4-gang glass black - Busch-art linear	1724-4025	1	piece
2CKA001754A4885	Cover frame 4-gang glass black / gold - Busch-art linear	1724-4013	1	piece
2CKA001754A4900	Cover frame 4-gang paper black - Busch-art linear	1724-4045	1	piece
2CKA001754A4890	Cover frame 4-gang wood oak - Busch-art linear	1724-4083	1	piece
2CKA001754A4895	Cover frame 4-gang wood walnut - Busch-art linear	1724-4086	1	piece
2CLA897400A1758	Cover frame 4-gang aluminium silver - Busch-art linear	1724-4073	1	piece
2CLA897400A2958	Cover frame 4-gang slate terra rosso - Busch-art linear	1724-4097	1	piece
2CKA001754A4869	Cover frame 5-gang studio white - Busch-art linear	1725-44G	1	piece
2CKA001754A4873	Cover frame 5-gang studio white - Busch-art linear	1725-44G-500	1	piece
2CKA001754A4870	Cover frame 5-gang studio white matt - Busch-art linear	1725-44M	1	piece
2CKA001754A4874	Cover frame 5-gang studio white matt - Busch-art linear	1725-44M-500	1	piece
2CKA001754A4872	Cover frame 5-gang black matt - Busch-art linear	1725-45M	1	piece
2CKA001754A4876	Cover frame 5-gang black matt - Busch-art linear	1725-45M-500	1	piece

2CKA001754A4926	Cover frame with decor ring 5-gang studio white matt / rose gold - Busch-art linear	1725-441M	1	piece
2CKA001754A4929	Cover frame with decor ring 5-gang studio white matt / rose gold - Busch-art linear	1725-441M-500	1	piece
2CKA001754A4928	Cover frame with decor ring 5-gang black matt / chrome - Busch-art linear	1725-456M	1	piece
2CKA001754A4931	Cover frame with decor ring 5-gang black matt / chrome - Busch-art linear	1725-456M-500	1	piece
2CKA001754A4927	Cover frame with decor ring 5-gang black matt / gold - Busch-art linear	1725-453M	1	piece
2CKA001754A4930	Cover frame with decor ring 5-gang black matt / gold - Busch-art linear	1725-453M-500	1	piece
2CLA897500A3958	Cover frame 5-gang glass blue - Busch-art linear	1725-4028	1	piece
2CKA001754A4881	Cover frame 5-gang glass black - Busch-art linear	1725-4025	1	piece
2CKA001754A4886	Cover frame 5-gang glass black / gold - Busch-art linear	1725-4013	1	piece
2CKA001754A4901	Cover frame 5-gang paper black - Busch-art linear	1725-4045	1	piece
2CKA001754A4891	Cover frame 5-gang wood oak - Busch-art linear	1725-4083	1	piece
2CKA001754A4896	Cover frame 5-gang wood walnut - Busch-art linear	1725-4086	1	piece
2CLA897500A1758	Cover frame 5-gang aluminium silver - Busch-art linear	1725-4073	1	piece
2CLA897500A2958	Cover frame 5-gang slate terra rosso - Busch-art linear	1725-4097	1	piece

## Categories

Products > Low Voltage Products and Systems > Building and Home Automation Solutions > KNX > User Operation > Control Elements > Cover Plates and Rockers

Products > Low Voltage Products and Systems > Wiring Accessories - Light Switch Ranges > Cover Plates and Control Elements > Mechanical Controls

