



PRODUCT-DETAILS

8574.1 BL

Frame 4-gang White - Sky Niessen



General Information

Extended Product Type:	8574.1 BL
Product ID:	2CLA857410A1101
EAN:	8427238135380
Catalog Description:	Frame 4-gang White - Sky Niessen
Long Description:	Color: Soft White Size (height x width): 86 x 299 mm White contour
Display Name:	8574.1 BL

Installation

Instructions and Manuals:	2CLX850009A1001
Type of Fastening:	Clamp
Mounting Orientation:	Horizontal Vertical

Environmental

Ambient Air Temperature:	Operation -5 ... +35 °C Storage -5 ... +50 °C
Degree of Protection:	IP20

Technical

Data Sheet, Technical Information:	9AKK107046A0356
Accessories Available:	Yes

Design

Design Range:	Sky Niessen Sky Essence
Surface Finishing:	Untreated Glossy
Material:	Plastic Thermoplastic
Label Space Provided:	Without Label Space
RAL Number:	RAL 9010 - Pure White
Color:	White
Number of Gangs:	4-gang

Dimensions

Product Net Width:	299 mm
Product Net Height:	86 mm
Product Net Depth / Length:	8.5 mm
Product Net Weight:	0.085 kg

Ordering

Replaced Product ID (OLD):	2CL0857411
-----------------------------------	------------

Material Compliance

RoHS Declaration:	2CLC00000009046
RoHS Information:	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
REACH Declaration:	2CLC00000004294
REACH Information:	True - contains substances > 0.1 mass percentage
REACH Date:	20251231
Conflict Minerals Reporting Template (CMRT):	9AKK108468A3363

SCIP: 5c6fa9f3-b5ca-45cb-93bf-fd8fb6e90433 Spain

WEEE Category: Product Not in WEEE Scope

Certificates and Declarations

Declaration of Conformity - CE: 9AKK106713A1744

EU Data Act Applicability and Compliance: Not Applicable

Popular Downloads

Marketing Video: 9AKK106930A1594
9AKK108468A9590

External Classifications and Standards

ETIM 9: EC000007 - Cover frame for domestic switching devices

ETIM 10: EC000007 - Cover frame for domestic switching devices

UNSPSC: 39121704

Accessories

Identifier	Description	Type	Qty	Unit Of Measure
ABB2CLA810100A1001	Insert Off switch 1-pole for 1 rocker, LED exchangeable/ 10 A	8101	1	piece
ABB2CLA850100A1101	Rocker Without imprint for Switch/push button, Single rocker White - Sky Niessen	8501 BL	1	piece
ABB2CLA810200A1001	Insert Two-way switch for 8102 1 rocker, LED exchangeable/ 10 A		1	piece
ABB2CLA811000A1001	Insert Intermediate switch for 1 rocker, LED exchangeable/ 10 A	8110	1	piece
ABB2CLA810400A1001	Push button insert Single push button for 1 rocker, 1 NO 0 NC 1 CO 10 A	8104	1	piece
ABB2CLA850400A1101	Rocker Symbol "bell" for Switch/push button, Single rocker White - Sky Niessen	8504 BL	1	piece
ABB2CLA811100A1001	Insert Series switch for 2 rocker, 10 A	8111	1	piece
ABB2CLA851100A1101	Rocker Without imprint for Switch/push button, Two-part rocker White - Sky Niessen	8511 BL	1	piece

ABB2CLA812200A1001	Insert Alternating -/alternating switch for 2 rocker, 10 A	8122	1	piece
ABB2CLA818800A1001	Socket outlet Without imprint - Platform 8100	8188	1	piece
ABB2CLA858800A1101	Cover socket outlet Without imprint White - Sky Niessen	8588 BL	1	piece
ABB2CLA811700A1001	Phone outlet For data connection housing Straight version 1gang	8117	1	piece
ABB2CLA851700A1101	Cover plate For data connection housing 1 gang White - Sky Niessen	8517 BL	1	piece
ABB2CLA815170A1001	TV/SAT outlet End socket	8151.7	1	piece
ABB2CLA855010A1101	Cover plate Sat 2 gang White - Sky Niessen	8550.1 BL	1	piece
ABB2CLA811900A1001	Buzzer - Platform 8100	8119	1	piece
ABB2CLA852900A1101	Cover plate Loudspeaker White - Sky Niessen	8529 BL	1	piece
ABB2CLA060250A1001	Socket outlet 25 A White Various	-6025	1	piece
ABB2CLA850000A1101	Cover for Blind plate with Without imprint White - Sky Niessen	8500 BL	1	piece
ABB2CLA810450A1001	Push button insert Single push button for 1 rocker, 1 NO 0 NC 1 CO 10 A	8104.5	1	piece
ABB2CLA850440A1101	Rocker Symbol "light" for Switch/push button, Single rocker White - Sky Niessen	8504.4 BL	1	piece
ABB2CLA814410A1001	Blind switch 1-pole push button 10 A	8144.1	1	piece
ABB2CLA854400A1101	Rocker Symbol "arrows" for Venetian blind Two- part rocker White - Sky Niessen	8544 BL	1	piece
ABB2CLA814400A1001	Push button insert 1-pole push button 10 A	8144	1	piece
ABB2CLA201860A1001	Insert for Rj45 1 gang - Platform 8100	2018.6	1	piece
ABB2CLA851810A1101	Cover plate For data connection housing 1 gang White - Sky Niessen	8518.1 BL	1	piece
ABB2CLA851820A1101	Cover plate For data connection housing 2 gang White - Sky Niessen	8518.2 BL	1	piece
ABB2CLA856020A1101	Cover plate Without imprint for Dimmer Turn button White - Sky Niessen	8560.2 BL	1	piece
ABB2CLA858500A1101	Cover USB charger White Sky Niessen	-8585 BL	1	piece

Categories

Products > Low Voltage Products and Systems > Building and Home Automation Solutions > free@home > User Operation > Frames

Products > Low Voltage Products and Systems > Building and Home Automation Solutions > KNX > User Operation > Frames

Products > Low Voltage Products and Systems > Wiring Accessories - Light Switch Ranges > Frames

